


A study of cleaning characteristics for EUV mask blanks

Kyoko Sakai, Yo Sakata,
Tadashi Matsuo, Keishi Tanaka

Product Innovation Laboratory,
TOPPAN PRINTING CO., LTD.



Contents

Introduction

Experimental

A TD-GC/MS analysis of organic compounds on EUV blanks

- after wet cleaning
- after keeping in conventional shipping cases
- after UV/O₃ treatment

B Measurement of effects on UV/O₃ treatment for EUV blanks


- EUV reflectance
- XPS analysis
- DUV reflectance (199nm,257nm : Defects inspection wavelength)

Summary

Introduction - Requirements for EUV mask

- **Organic contamination control**


Organic compounds cause carbon contamination in the vacuum chamber, which degrades the reflectance of EUV mask.




Introduction - Dry cleaning methods

UV/O₃ treatment

Excimer lamp @ 172nm
10.2mW/cm²




UV/O₃ treatment is one of dry cleaning methods to remove organic compounds by photo-oxidative decomposition.




UV/O₃ treatment may also cause the reflectance degradation by oxidation of EUV mask surface.

Experimental - Sample structure




Experimental A - Procedure




Experimental A - Organic analysis tool

TD (Thermal desorption) - GC/MS



He gas flow control



TD condition

30
300 (15 /min)
300 (42min hold)


GC condition

40 (5min)
280 (10 /min)
280 (21min hold)


Experimental A-1 - TD-GC/MS analysis

Ru


Reference




After keeping in ABS case



After wet process



After keeping in Acrylic case




Retention time

- straight-chain hydrocarbons
- ketone

Experimental A-2 - TD-GC/MS analysis


After keeping in Acrylic case




Experimental A-3 - TD-GC/MS analysis

LR-TaSi

Reference




After keeping in ABS case




· aromatic hydrocarbons

After wet process




After keeping in Acrylic case



· straight-chain hydrocarbons


Experimental A-4 - TD-GC/MS analysis

After keeping in Acrylic case




Organic compounds derived from acrylic case were successfully removed.

Experimental B - Procedure




Experimental B-1 - EUV reflectance



Both reflectance curves were almost overlapped.

Experimental B-2 - XPS analysis

Ru

| | angle | area ratio |
|--------------------------|-------|-------------------------|
| | | O1s/Ru3d _{5/2} |
| Before UV/O ₃ | 45° | 1.0 |
| | 25° | 1.7 |
| After UV/O ₃ | 45° | 1.1 |
| | 25° | 1.8 |

Differences of area ratio between before/ after UV/O₃ were within experimental accuracy.

No significant Ru surface oxidation by UV/O₃ was confirmed.

Experimental B-3 - DUV reflectance

Ru

LR-TaSi

| R% | 199nm | 257nm |
|--|-------|-------|
| after UV/O ₃ - before UV/O ₃ | | |
| Ru | 0.16% | 0.16% |
| LR-TaSi | 0.40% | 0.30% |

Differences of between before/ after UV/O₃
were equivalent to experimental accuracy.

No remarkable change of reflectance
between before / after UV/O₃ was confirmed.

Summary

- Few organic compounds after wet process exist on Ru capping and LR-TaSi absorber, equivalent to reference.
- A lot of organic compounds were detected on Ru capping and LR-TaSi absorber after keeping in acrylic shipping case.
- UV/O₃ cleaning was found an effective means for removing organic compounds derived from shipping case.
- EUV reflectance and surface oxidation on Ru capping didn't change significantly by UV/O₃ treatment for 20min.
- Reflectance at 199nm, 257nm on Ru capping and LR-TaSi absorber didn't change by UV/O₃ treatment for 20min.

Acknowledgement

The authors would like to thank Selete
for EUV reflectance measurement.