

Evaluation of EUV mask pattern inspection using DUV reticle inspection tool

Tsukasa Abe, Takashi Adachi, Tadahiko Takikawa, Hiroshi Mohri,
Hidemichi Imai, Yasushi Sato and Naoya Hayashi

¹ Dai Nippon Printing Co., Ltd. (Japan)




Contents

- Introduction
- Experimental
 - Test sample
 - Evaluation tool
 - Designed defect
 - Defect printability simulation
- Inspection results
 - Si capping CrN buffer structure
 - Ru capping structure
- Real defect sample
- Summary




Introduction


- Differently from optical photomask, EUV mask defect inspection uses only reflected light



Inspection test sample



Reflectivity curve of EUV mask



Courtesy of HOYA

Optical property was optimized for defect inspection
with 257nm wave length




Evaluation tool

- Program defect size measurement
 - CD-SEM
 - : KLA 8250R
 - Pattern edge detection & area size measurement
 - : In-house software
- Defect print simulation
 - Kirchhoff simulation.
- Inspection tool : KLA586
 - Wave length 257nm / Pixel size 90nm
 - DD / DB



Programmed defect

Resist patterning : 50kV EB writer with PCAR 300nm
Main pattern : 1:1 dense line
Main pattern size : hp 260nm/180nm @ mask




SEM images : main pattern size 260nm



Program defect size measurement



Defect size definition

1. **Measured defect size = square root of area (nm)**




2. **CD error = |defect line CD - reference line CD|**

Defect size measurement results




Defect printability simulation sample



Optical image on wafer
1x1 opaque extension




1x2 opaque extension





Programmed defect SEM image

5% CD error







10% CD error



1x1 clear extension



1x2 clear extension




~hp 180nm l/s~



Defect inspection results


~Si cap / CrN buffer structure : 260nm hp ~



Inspection sensitivity difference between w/ and w/o buffer pattern was not observed

EUVL symposium 2007

Light intensity profile of defect



Good light intensity profile was obtained at 260nm pattern.



Defect inspection results



~Si cap / CrN buffer structure : 180nm hp ~

	sample	Mode	Tool	Pixel	Algorithm	Sensitivity	#runs
a	w buffer	DDR	KLA5X6	P90	UPA	high	5
b	w/o buffer	DDR	KLA5X6	P90	UPA	high	5



No	0	1	2	3	4	5	6	7	8	9
	pin hole	pin dot	line cut	bridge	1x1 clear exte	1x1 opaque ex	1x2 clear exte	opaque exte	small CD	large CD
	size a b	size a b	size a b	size a b	size a b	size a b	size a b	size a b	size a b	size a b
0									1.7	0.4
1									4.1	2
2									3.9	2.5
3									7.5	4.8
4			50						7.2	6.3
5			71				38	24	11	11
6			79	24	27		43	35	13	11
7			94	32	37	16	58	34	15	14
8			119	36	40	26	53	43	17	14
9			127	50	51	12	63	46	22	60
10			131	54	55	28	73	20	22	21
11			136	64	59	37	84	61	24	21
12			142	75	61	38	92	72	27	26
13			146	76	68	49	93	75	26	28
14			148	103	76	50	103	84	30	29
15			151	106	84	54	113	89	34	30
16			152	120	87	58	120	98	33	32
17	42		153	123	93	68	126	102	38	35
18	137	40	155	126	104	67	133	116	38	39
19	137		157	129	104	76	144	115	42	40
20	145		159	135	112	78	149	124	44	39
21	151	57	165	143	117	85	157	134	46	43
22	152	74	170	141	123	86	162	138	48	43
23	160	101	166	148	126	88				
24	161	119	170	147	149	100				
25	168	133	174	156	151	104				
26	169	141	174	159	161	109				
27	175	147	180	163	165	116				
28	176	153	175	166	172	122				
29	178	164	176	173	175	149				
30	179	165	182	174	178	158				

— 5% CD error
— 10% CD error
(by simulation)

1x2 clear extension defect : Defect size 93nm



1x2 opaque extension defect : Defect size 75nm



Defect inspection results

~ Ru Capping structure ~

~ 260 nm hp ~

	Mode	Pixel	Algorithm	Sensitivity	#runs
a	DDR	P90	UPA	high	10
b	DDR	P90	UPA	high	10

No	0	1	2	3	4	5	6	7	8	9
	pin hole	pin dot	line cut	bridge	1x1 clear extens	1x1 opaque exte	1x2 clear extens	2 opaque extens	small CD	large CD
	size a b	size a b	size a b	size a b	size a b	size a b	size a b	size a b	size a b	size a b
0										
1									3.0	1.3
2									2.9	3
3									5.7	5.9
4									7.0	9
5									10.3	10
6									10.2	12
7									15.9	15
8									17.1	16
9									19	80
10									20.5	22
11									22.8	21
12									23.7	26
13									26.5	26
14									26.8	30
15									32.2	29
16									34.1	31
17									37.2	35
18									40	35
19	94.9								40.6	40
20	94								40	43
21	88								48	42
22	110								48	46
23	116								49	48
24	119								50	49
25	129								51	52
26	144								54	54
27	171								49	62
28	183								58	57
29	186								61	62
30	200								63	62

~ 180 nm hp ~


	Mode	Pixel	Algorithm	Sensitivity	#runs
a	DDR	P90	UPA	high	10

No	0	1	2	3	4	5	6	7	8	9
	pin hole	line cut	bridge	bridge	1x1 clear extension	1x1 opaque extension	1x2 clear extension	1x2 opaque extension	small CD	large CD
	size a	size a	size a	size a	size a	size a	size a	size a	size a	size a
0										
1									4.0	1.8
2									5.1	2.4
3									9.3	6.1
4									9.5	7.8
5									13.2	7.0
6									13.1	12.4
7									16.6	13.3
8									18.6	15.0
9									20.6	19.4
10									22.9	21.1
11									24.9	23.1
12									26.8	24
13									28.9	26.4
14	38								31.7	29.4
15	56								33.1	30.4
16	112								37.1	32.4
17	135								39.4	33.4
18	140								40.6	37.6
19	143								41.3	40.7
20	156								44	41
21	156								48	43
22	160	26	40						51	45
23	161	95							49	47
24	165	119							52	49
25	169	128							57	52
26	176	137							60	55
27	177	150							60	56
28	180	154							63	59
29	181	182							65	61
30	190	164							69	63



Sensitivity difference between hp260nm to hp180nm

Minimum defect size detected by DD mode



- ◆ Inspection sensitivity of hp180nm pattern is slightly lower than hp 260nm pattern
- ◆ Inspection sensitivity of Ru capping sample is close to Si capping sample.




DUV review images of real defect



Sample Si capping w/o buffer / Inspection mode : DDR

Defect sample A Defect sample B Defect sample C

Test image



Reference image



difference image



(Opaque defect exist at reference image)


Naturally occurring clear defects were not observed.

EUVL symposium 2007



Wafer print samples of program defect

Main pattern size 325nm hp on mask (65nm on wafer)



Wafer print images : ASET

Summary

- EUV mask defect inspection was evaluated using current DUV inspection tool.
 - DUV inspection tool has potential for EUV mask defect inspection.
(Need sensitivity improvement for 3X nm node and beyond)
 - Inspection sensitivity difference was not observed between w/ and w/o buffer surface.
 - Defect sensitivity of hp180nm pattern was slightly lower than hp 260nm pattern.
 - Inspection sensitivity of Ru capping sample was close to Si capping sample.

Future work

- Defect inspection using smaller pixel size / shorter wave length light



Acknowledgement

We would like to thank

- Dr. Shoki of HOYA for DUV reflectivity data
- ASET, SEMATECH and LBNL for wafer print data of program defect

