

Improvements for the Small Field Exposure Tool (SFET) in Selete

**Seiichiro Shirai, Shunko Magoshi, Tawarayama Kazuo,
Yuusuke Tanaka, Miyoshi Seki, Hiroyuki Tanaka**

EUVL Process Program

Semiconductor Leading Edge Technologies, Inc.



Semiconductor Leading Edge Technologies, Inc.

SFET configuration and history

SFET objective

- Utilized for research and development of EUVL masks and resist materials.



configuration

| item | specification |
|---------------|---------------|
| NA | 0.3 |
| Field size | 0.2x0.6mm |
| Magnification | 1/5 |

History

2006

- Sep Exposure experiments start in Canon, Utsunomiya
- Nov Move-in to Selete

2007

- Apr Evaluation start
- Nov Alignment tool installation
- Illumination replacement (critical→koehler)

2008


- Jan Thermal insulator installation
- Apr SPF (Spectral Purity Filter) optimization

2009

- Jan FFP (Far Field Pattern) monitor installation
- Feb Xe flow rate control application
- Jun High-voltage resistance MSC (Magnetic Switching Core) tower installation

Improvements for SFET

| item | | outline | period |
|----------------------|---------------------------|--|----------|
| Accuracy | Focus stability | Focus variation improved from 72nm(3sigma) to 30nm | Jan 2008 |
| Light axis alignment | Alignment tool | Utilized for the light axis adjustment on QC | Nov 2007 |
| | FFP monitor | Utilized for the light axis adjustment every collector and DMT replacement | Jan 2009 |
| Throughput | SPF optimization | SPF position and specification change contributed to a high output and gain of 60% | Apr 2008 |
| | Xe flow rate optimization | Xe flow rate optimization contributed to a high output and gain of 30% | Feb 2009 |
| Reliability | | High-voltage resistance MSC tower installation | Jun 2009 |





Focus variation in an early stage of SFET evaluation

Wafer stage temperature variation
0.194°C/72hrs without thermal insulator



0.032°C/72hrs
with thermal insulator






Focus variation histogram

- Focus stability has improved from 72nm to 30nm with wafer stage temperature stabilization through the installation of the thermal insulator.



Alignment of the light axis

- Essential to optimize the axis of the light from the light source to IF point.




| Tool | Application | Characteristic |
|----------------|----------------------------|---|
| Alignment tool | Daily QC | • Instant measurement (1min/meas.) |
| FFP monitor | collector, DMT replacement | • Fine observation • Time-consuming measurement (3hrs/meas.) |

- Possible to observe the image position at the 2nd IF with CCD with the insertion of a movable mirror.




Collector adjustment







Far Field Pattern Monitor


- Possible to observe Far Field Pattern with CCD.
- Compact design for insertion in koehler illumination chamber.



FFP monitor application

| Date | Feb-2007 | Mar-2008 | Aug-2008 | Feb-2009 | Jun-2009 |
|---------------------------|---|--|--|---|---|
| | Installation | Collector and DMT replacement | DMT replacement | DMT replacement | Collector and DMT replacement |
| Collector | #1 | #2 | #2 | #3 | #4 |
| DMT | #1 | #2 | #3 | #4 | #5 |
| Adjustment of light axis | Inconvenient FFP monitor (Need to separate Source Head from SFET) | | Alignment tool and pupilgram (exposed wafers) | FFP monitor | |
| Far Field Pattern |  Φ4mm aperture |  Φ3mm aperture | N/A |  Φ0.5mm aperture |  Φ0.5mm aperture |
| Approximate time required | >7days | >7days | >10hrs | <3hrs | <3hrs |

- Applicability of thinner SPF while avoiding damage possible by keeping away SPF from plasma.



| SPF | specification | transmittance | Intensity ratio |
|-----|-----------------------------|---------------|-----------------|
| Old | Si(50nm)/Zr(150nm)/Si(50nm) | 29% | 1.0 |
| New | Zr(100nm) | 47% | 1.6 |

- SPF position and specification change improved output by 60%.

Xe flow rate optimization







Diagram plasma position during electrode life-time




- Due to electric field and Xe density distribution change, caused by electrode geometry, Xe flow rate optimization is required.

Xe flow rate optimization results




- Xe flow rate optimization contributed to a high output and gain of 30%.

EUV light intensity trend



• EUV light intensity has almost tripled in magnitude.

Total number of wafer exposed by SFET in the last 2 years



▪ More than 2,200 wafers exposed.

- The SFET has been utilized for research and development of EUVL masks and resist materials since it was installed in Selete, 2007, April.
- Various improvements have been made for the SFET in last 2 years.
 - Focus stabilization

With thermal insulator, the wafer stage temperature was stabilized within 0.032°C for 72hrs, contributing to a stability improvement from 72nm (3sigma) to 30nm.
 - Alignment of the light axis

Essential to adjust the optical axis between the light source and IF point to maintain a high output.

 - * Alignment tool

Utilized for every daily QC.
 - * FFP monitor

Utilized for every collector and DMT replacement.
 - Throughput

- * SPF position and specification change**

Applicability of thinner SPF while avoiding damage possible by keeping away SPF from plasma. The thinner SPF improved output by 60%.

- * Xe flow rate optimization**

Due to electric field and Xe density distribution change, caused by electrode geometry, Xe flow rate optimization is required.

Xe flow rate optimization contributed to high output and gain of 30%.

- EUV light intensity has almost tripled in magnitude and the total wafers exposed by the SFET for the last 2 years reached more than 2,200 wafers.**

[Future plan]

- Application of higher EUV source voltage (on going, Jun 2009-)**

Plan to increase applied voltage from 1.8kV to 2.0kV to achieve higher output.

- Job reservation function installation**

Automatic and successive processing of multiple wafers of different process conditions possible.

This work was supported by NEDO.

**This work was possible with the cooperation of
CANON INC., USHIO INC. and XTREME technologies.**

End



Semiconductor Leading Edge Technologies, Inc.