




Development of positive - tone molecular resist based on Phenyl[4]calixarene for EUVL

Masatoshi Echigo, Yu Okada, Hiromi Hayashi, and Masaaki Takasuka

Mitsubishi Gas Chemical Company, Inc.




Approach from Positive - tone Resist Material for LER Reduction








Design Concepts for New Positive - tone Molecular Resist Material Cross - linked with Protection Group




Synthesis Scheme of Molecular Resist Material Cross - linked with Protection Group



MGR104



R = H or



MGR104P - CHDVE

Molecular resist material cross-linked with protection group,
MGR104P - CHDVE, was synthesized.




Solubility of Molecular Resist Material Cross - linked with Protection Group

	Reaction ratio of MGR104 / CHDVE (mol%)	Solubility for Resist Solvent ¹⁾	Solubility for Alkaline Developer ²⁾
Run 1. MGR104P—CHDVE50	1 / 2 (50mol%)	Insoluble	-
Run 2. MGR104P—CHDVE25	1 / 4 (25mol%)	Soluble	Soluble
Ref. MGR104	No protect (0mol%)	Soluble	Insoluble


1) PGME (1 - Methoxy - 2 - propanol)

2) Conventional Alkaline Developer (0.26N TMAH aq.)

MGR104 cross-linked with CHDVE (25mol%),
MGR104P-CHDVE25, is suitable for positive-tone resist material.




R = H or




MGR104P - CHDVE25

- Amorphous
- High Etching Durability
(Etching rate is same as PHS)
- High Glass Transition Temperature
- Good Solubility for Resist Solvents
- Good Solubility Rate for TMAH0.26N%aq.
as a Positive - tone Resist Base.



The molecular weight of MGR104P-CHDVE25 is higher than that of MGR104.




Insoluble for
TMAH0.26N%aq.

MGR104P-CHDVE




H^+ / H_2O



MGR104

+



+

$H_2C=O$

Soluble for
TMAH0.26N%aq.



EB Patterning Evaluations

Tool:


Ultra - High Precision EB Lithography System
(ELS - 7500 ; Acceleration Voltage 50 keV)
at Mitsubishi Gas Chemical (MGC)

Process Conditions:


Substrate: Organic layer (UL)
Film Thickness: 40 - 60nm
PB & PEB: 70 - 110 / 90s
Dev.: TMAH 0.26N 60s



	Positive - tone Resist A
Resin	MGR104P - CHDVE25
PAG	TPS - PFMS
Quencher	TOA
Solvent	PGME



TPS - PFMS




TOA

Resist formulation hasn't been optimized yet !!








Patterning results of Resist A by EB



Sub 30nm patterns were resolved by EB.
However, the pattern wasn't be prevented from collapsing.



Patterning results of Resist A by EUV - IL



*By courtesy of
University of Hyogo*

25nm patterns were resolved by EUV - IL. However, the pattern wasn't prevented from collapsing.

2010.10.18

2010 International Symposium on EUVL

- We have developed new positive - tone molecular resist material cross - linked with protection group, MGR104P - CHDVE25. We investigated the application to positive - tone resist for EB and EUVL.

EBL: Resolution showed **Hp 30 nm** at an EB dose of **42 μ C / cm²**.

EUVL: Resolution showed **Hp 25 nm** by EUV - IL.

- We confirmed the possibility of new positive - tone molecular resist material cross - linked with protection group for EB and EUVL.



Acknowledgement

- We would like to thank to Dr. T. Watanabe, Mr. Y. Fukushima and Dr. H. Kinoshita of University of Hyogo for useful discussions and for the evaluated by EUV - IL.