

EUV mask pattern inspection using EB projection optics

Tsuyoshi Amano, Susumu Iida, Ryoichi Hirano, Tsuneo Terasawa, Hidehiro Watanabe EUVL Infrastructure Development Center, Inc.

Masahiro Hatakeyama, Takeshi Murakami EBARA corporation



Introduction



Detecting the defects of smaller than 18 nm in size is required for the hp 16 nm EUV mask in ITRS 2010 update. In order to achieve the inspection sensitivity and applicability for hp 16 nm, we utilized an inspection system with projection EB optics. The projection inspection system has potential to take clear images of small patterns than that by DUV and to inspect masks with higher throughput than that of SEM inspection system.

We demonstrated the basic performance of imaging quality and inspection sensitivity. The detectability of thin absorber defect was also discussed.



Our goal



EUVL mask requirements (ITRS roadmap 2010 update)

Year of Production	2011	2012	2013	2014	2015	2016	2017	2018	2019	2020
DRAM 1/2 pitch (nm) (contacted)	40	36	32	28	25	23	20	18	16	14
Flash 1/2 pitch (nm) (un-contacted poly)	28	25	23	20	18	16	14	13	11	10
MPU/ ASIC Metal 1 (M1) 1/2 pitch (nm) (contacted)	38	32	27	24	21	19	17	15	13	12
Mask minimum primary feature size (nm)		88	78	70	62	, ⁴ 55 \	49	44	39	35
Defect size (nm)		29	25	23	20 (18	, 16	14	13	11


Our target is


- defect detection of 18 nm in size.
- 13 hours of inspection throughput.



Inspection with PEM(Projection Electron Microscope) technique








	PEM	SEM				
Optics	Wide irradiation	Point irradiation				
Detector	Area sensor	Point detector				



History of inspection system using PEM technique







Experimental conditions



Experimental PEM system for 1x-nm EUV mask pattern inspection

E-gun: LaB₆

Detector: CCD

Pixel size: 20 nm

Irradiation area: 100x50 um

Landing energy: 0-3000 eV

EUV mask structure and pattern

Mask structure: LR-TaBN(51 nm), CrN(10 nm),

Si-cap.(11 nm), ML(40 pairs)

Mask pattern: hp 80 - 400 nm(for image quality test)

hp108, 128 nm (for defect inspection test)




Image quality

hp 128 nm L/S




- Imaging time dependent MTF curve -



50%-MTF is one of the reference indexes of image quality. We obtain 60%-MTF at 50 msec imaging time but the MTF value quickly fell below 50 msec.



Image quality MTF value vs. L/S half-pitch




50%-MTF was achieved from hp 80 to 400 nm CD range.



Defect signal-noise ratio






Defect SNR=1 means detection limit.


The noise reduction is one of the major challenges to achieve detection defects of < 20 nm in size.

Defect signal-noise ratio










The 24 nm size of edge extension defect was successfully identified.

Example of defect detection signal





Noise sets a limitation of the inspection sensitivity.



Capability of thin absorber defect detection EBARA

Simulation Condition

Beam: Projection beam

Pattern: 66 nm height

hp 88 nm L/S


Defect: Thin absorber defect

Charging: no

Thin absorber defect

Defect (TaN) height is varying with


66 nm (full height), 33 nm, 2 nm, 0 nm





Simulation result





PEM system has a capability to catch the 2 nm thick of thin absorber defect.



Summary



The basic performance of the PEM technique was evaluated using experimental PEM system.

Clear images of hp 80 nm L/S with 50%-MTF were obtained under the condition of 50 msec imaging time.

Defect of 24 nm size in hp 88 nm L/S was successfully identified.

EB simulation result suggests that the PEM system has a capability to catch the thin absorber defects.



Acknowledgements



Authors would like to thank to

Masamitsu Ito

Takashi Hirano

Shinji Yamaguchi and

Masato Naka

of Toshiba Corporation for their technical advice.

Kenji Terao

Takehide Hayashi and

Kenji Watanabe

of EBARA CORPORATION for their technical support.

This work was supported by New Energy and Industrial Technology Development Organization (NEDO).

