

Basic performance evaluation of novel Projection Electron Microscopy (PEM) system for EUV mask pattern inspection

Ryoichi Hirano, Susumu iida, Tsuyoshi Amano,
Hidehiro Watanabe, Tsuneo Terasawa
EUVL Infrastructure Development Center, Inc.

Masahiro Hatakeyama, Takeshi Murakami
EBARA CORPORATION

Introduction

Detecting the defects of smaller than 18 nm in size is required for the hp 16 nm EUV mask as described in ITRS 2011 edition. In order to achieve the inspection sensitivity and the extendability for 1x node, Projection Electron Microscope (PEM) technique with higher electron energy in imaging and exposure Electron Optics (EO) are developed.

We demonstrated the basic performance of Novel PEM technique by using developed EO. EO transmittance and image resolution are measured on an evaluation vacuum chamber.

Defect detection requirement

EUVL mask requirements (ITRS 2011 edition)

Year of Production	2011	2012	2013	2014	2015	2016	2017	2018	2019	2020
DRAM 1/2 pitch (nm) (contacted)	36	32	28	25	23	20	18	16	14	13
Flash 1/2 pitch (nm) (un-contacted poly)	22	20	18	17	15	14	13	12	11	10
MPU/ASIC Metal 1(M1) 1/2 pitch (nm) (contacted)	38	32	27	24	21	19	17	15	13	12
Mask minimum primary feature size (nm)	99	88	78	70	62	55	49	44	39	35
Defect size (nm)	29	25	23	20	18	16	14	13	11	10

<18 nm size defects are necessary to be detected by hp16 nm EUVL mask inspection.

History and advantages of inspection system using PEM technique

DUV inspection


High throughput
Image resolution limited by λ

EB-SEM type inspection

High image resolution
Low throughput(point beam)

PEM has the advantage of DUV inspection and that of EB-optics.

History of MODEL EBEYE ("Model EBEYE" is EBARA's model code)



alpha_tool
•200 mm Wafer
•D/R= 600 MPPS
D/R (Data Rate)




Model EBEYE 300
•200/ 300 mm Wafer
•D/R= 600 MPPS



Model EBEYE M
•EUV Mask
•D/R= 600 MPPS


M. Hatakeyama et al., PMJ2012

PEM: Projection Electron Microscope TDI (Time Delay Integration) sensor




R. Hirano et al., PMJ2012

Improvement of imaging electron optics





T. Hirano et al., SPIE vol. 7823



**Signal beam profile depends on e⁻ energy in imaging EO.
Imaging EO using high energy electron will achieve x1.4
resolution of EO for hp 2X nm.**

Transmittance improvement in imaging and exposure EO

	hp 2X nm tool	Novel PEM optics
Transmittance in imaging EO	1	≥ 2
Transmittance in exposure EO	1	≥ 10
Total	1	≥ 20



Imaging electrons are increased by higher transmittance at same capture rate.

More than x20 improvement of transmittance is required on Novel PEM optics are needed. It leads to x0.22 noise reduction comparing to 2X nm tool PEM optics.


Novel PEM optics development

EIDEC developed high resolution and high throughput PEM optics Model EBEYE-V30.

We have finished the assembly of newly designed column.


The column was installed on an evaluation vacuum chamber.

Transmittance of exposure and imaging optics were measured. Image resolution of imaging optics was estimated by captured pattern sample image.




Evaluation for exposure and imaging unit performance

- ✓ Transmittance of exposure and imaging unit were calculated by the ratio of input to output.
- ✓ Image resolution was evaluated by measuring sample pattern electron image.



Transmittance evaluation of exposure and imaging unit



Transmittance improvement design of developed PEM optics

Transmittance of exposure and imaging unit were measured by the ratios of input to output.




- ✓ Exposure EO : $(\text{Si-photodiode}) / (\text{Beam source power})$
- ✓ Imaging EO : $(\text{Detector}) / (\text{Photoelectron})$

Designed transmittance of exposure and imaging EO were confirmed by measurements.


Pattern sample for imaging unit performance evaluation

hp 1 μm to 64 nm patterns were fabricated on pattern sample.


Electron image was acquired using the sample patterned mask made of shading pattern layer on photoelectron emitting film illuminated by DUV laser.




Electron image of pattern sample



hp 1um L/S



hp 100 nm L/S



hp 64 nm L/S

Image resolution evaluation

Edge slope was calculated from captured image.
Compared with 2X nm tool designed value, expecting image resolution improvement was confirmed.







Image resolution evaluation (cont'd)

Line spread function (LSF) is obtained as the differential of measured edge profile. L/S pattern profile image can be calculated as the convolution of the LSF with L/S pattern rectangular wave.

Estimated image contrast at hp 64 nm pattern was consistent with designed value.



Calculated hp 64 nm profile from experiment



Summary

The basic performance of Novel (PEM) technique was demonstrated using developed EO.

- ◆ Transmittances of exposure and imaging unit were measured as the ratio of input-to-output electrons. The values were confirmed to be exceeding the designed values.
- ◆ Image resolution was evaluated from sample mask electron image.
- ◆ Obtained hp 64 nm image contrast was consistent with designed value.
- ◆ The developed EO has a potential to realize EUV mask pattern inspection for hp 16 nm generation and beyond.

Next step

Basic performance evaluation of integrated exposure and imaging optics

Acknowledgements

Authors would like to thank to
Shinji Yamaguchi and
Masato Naka

of Toshiba Corporation for their technical advice.

Kenji Terao
Yoshihiko Naito and
Kenji Watanabe
of EBARA CORPORATION for their technical support.

This work was supported by New Energy and Industrial
Technology Development Organization (NEDO) and
Ministry of Economy, Trade and Industry (METI).