

Chemically Amplified EUV Resist and Materials Development for 22 nm Half Pitch and Beyond


Makoto Shimizu
JSR Corporation

2012 International Symposium on
Extreme Ultraviolet Lithography


Brussels, Belgium
30 September – 4 October 2012



High Resolution Material




All images are single point in the field exposed with dipole-30X at a dose of 33mJ/cm² and




Ref. Tom Wallow et al, SPIE2012 8322-54

- **JSR chemically amplified resist (CAR) achieved sub 18 nm hp resolution at LBNL MET**
- **LWR and Sensitivity improvement is required**

How to design EUV resist




ArF, 10 mJ/cm^2 , $\alpha = 4/\mu\text{m}$
 $n_{\text{absorbed}} = 366528$, $E_{\text{absorbed}} = 2354 \text{ keV}$



EUV, 10 mJ/cm^2 , $\alpha = 1/\mu\text{m}$
 $n_{\text{absorbed}} = 25328$, $E_{\text{absorbed}} = 2326 \text{ keV}$

Wavelength (nm)	k ($\alpha \mu\text{m}^{-1}$)	QY	Available # Ph/CH area	Available # Ph/nm ²	Ph lost
13.5	0.0068 (6.3)	5.00	4931	~10	78%
193	0.0347 (2.3)	0.25	70488	~146	91%


$$\alpha = 4\pi \cdot \frac{k}{\lambda} \quad \#Ph = \text{dose} \cdot \frac{\lambda}{C \cdot h} \quad Ph_{\text{abs}} = Ph_{\text{t}} \cdot (1 - e^{-\alpha t(\lambda)}) \quad H_{\text{gen}}^+ - Ph_{\text{abs}} = QY$$



A. Vaglio Pret, K. Garidis, R. Gronheid, J. Biafore

- Less photons are available for patterning at EUV compared to ArF lithography
- EUV resist development should consider materials that use EUV photon effectively in resist design

High Resolution Resist Design










High Absorbance EUV Resist: RLS Performance

Resin	Absorbance Unit	22nm HP	20nm HP	19nm HP
Low Absorbance	Standard	Sen.:17.2mJ/cm ² LWR:5.8nm	Sen.:17.2mJ/cm ² LWR:5.5nm	Sen.:17.2mJ/cm ²
High Absorbance	25 % Up	Sen.:15.0mJ/cm ² LWR:5.5nm	Sen.:15.0mJ/cm ² LWR:5.8nm	Sen.:15.0mJ/cm ²

LBNL MET, NA0.3, 18nm Dipole

- *Increasing EUV resin absorbance improves resist sensitivity (13 %)*
- *Effect of increasing EUV absorbance and absorbance unit was investigated to balance RLS performance*

High Absorbance EUV Resist: Effect of Absorbance Unit





	Standard Resin	Absorbance Resin-A	
Polymer Structure		 Applied 3 rd unit in polymer	 Protecting Group  Polar unit  Absorbance Unit
Transparency @13.5nm (calculation, relative)	100	95	
Dill's C-parameter	0.04	0.05	
Litho performance 26nmLS Eop LWR			


Courtesy of EIDEC

- **Higher EUV absorbance resist showed higher sensitivity**
- **High absorbance resist showed higher Dill's C-parameter. It suggests that higher absorbance resin accelerate acid generation**





LWR Mitigation Study: Mole Ratio of Absorbance Unit


	Absorbance Resin-A	Absorbance Resin-A'
Polymer structure	 Std	 Absorbance unit up
Transparency @13.5nm (calculation, relative)	95	93.5
Dill's C-parameter	0.05	Under analysis
Litho performance 20nmLS Eop LWR	 17.2 5.5	 15.0 5.8



- **Resin-A' having higher amount of absorbance unit showed higher absorbance at 13.5nm**
- **Resin-A' showed higher R_{min} . R_{min} affects dissolution contrast**

New High Absorbance Resin: Control Dissolution Property

	Absorbance Resin-A	New absorbance Resin-B
Polymer structure		 Applied new 3 rd unit
Transparency @13.5nm (calculation, relative)	95	93.5
Tg	std	std + 20deg
Dill's C-parameter	0.05	Under analysis







 : New Absorbance Unit

- Resin-B with new absorbance unit showed higher Tg and higher absorbance
- Resin-B suppressed R_{min} and improved dissolution contrast

New High Absorbance Resist: RLS Performance



	Resin-A	Resin-B
Top view @25nmhp		
Dose to size (mJ/cm ²)	11.4	13.4
LER (nm)	4.1	3.4
Top view @22nmhp		
Dose to size (mJ/cm ²)	11.0	12.8
LER (nm)	4.4	3.9

NXE3100, NA0.25, Dipole60X

Summary

- ***Sensitivity and LWR improvements are significant challenges for 16 nm hp generation***
 - ***High absorbance resin with different absorbance unit was developed and investigated for 22 nm patterning performance***
 - ***High absorbance resin showed higher absorbance at EUV. Higher Dill's C-parameter for high absorbance resist suggests that high absorbance resin accelerate acid generation***
 - ***Higher absorbance unit affects thermal properties and dissolution contrast***
 - ***EUUV resist containing high absorbance resin improved resist sensitivity***
 - ***EUUV resist with 2nd generation high absorbance resin achieved balanced RLS performance at 22 nm hp ($E_s = 12.8 \text{ mJ/cm}^2$; LER = 3.9 nm) on NXE:3100***

Acknowledgment

JSR gratefully thank imec and SEMATECH, for their close collaboration and giving us many evaluation opportunities.



Reference

- Tg measurement => Refraction index measurement

Reference; **Brainard, R. L. et al.**, *Proc. SPIE*, 2012, 8322-07

- Transmittance calculation under 13.5nm wavelength

Reference; <http://www.cxro.lbl.gov/>

CXRO at Lawrence Berkeley National Laboratory

- Dill's C parameter => Φ acid

Reference; **Charles R. Szmanda. et al.**, *J. Vac. Sci. Technol. B*, 1999, 3356

$$\frac{dP(D)}{dD} = -CP(D) \Rightarrow P(D) = P_0 e^{-CD}$$

$$\Rightarrow A(D) = P_0 (1 - e^{-CD}),$$

Thank you for your attention !!

Materials Innovation



With chemistry, we can.