EUVL Image-based Aberration Metrology

Germain Fenger+*

Bruce W. Smith+, Sudharshanan Raghunathan*, Lei Sun*, Thomas Wallow*, Deniz Civay*, and Obert Wood*

+Rochester Institute of Technology

*GLOBALFOUNDRIES




EUVL challenges

- Source Power
- Resist
- Optics
- Illumination
- Reticle Defectivity & inspection/ repair
- Shadowing
- Flare
 - Scales with λ, EUVL needs ~14x lower roughness lens than ArF
- Aberrations
 - EUVL aberrations levels need to be controlled to $\lambda/20$ or better, while ArF needs $\lambda/100$
 - Additional concerns, which are manageable in ArF, but maybe a concern in EUVL include: thermal drift, monitoring, tool matching, & lens degradation
 - Measurement & monitoring will likely be more critical than other lithography generations
 - Image based aberration metrology has a window of opportunity with EUVL

Benefits of estimating lens aberrations from lithographic images

- Has been used previously in DUV applications
- Uses well characterized photoresist process
- Targets are readily available on current IC reticles
- Ability to monitor aberration levels during system use
- Can be easily accomplished with a small amount of metrology and exposure time
- Not a replacement for onboard metrology, but a complementary method

Wavefront aberration




EUVL System under study

- ADT
 - Partial coherence 0.5, 0.25 NA, 4X, full field
- MET
 - Programmable illumination, 0.3 NA, 5X, 1x3mm field
- NXE3300
 - Variable partial coherence, 0.32 NA, 4X, full field
- Other EUVL systems

Aberration test target selection ADT, 0.25 NA, σ=0.5

Criteria

- Easily available on current EUVL reticles
- Diffraction orders interact with aberration of interest in the pupil plane
- High resist CD change for a given aberration level
- Partial coherence of 0.5 causes higher order aberrations to be averaged with lower order aberrations in all targets



Binary Mask Structure	{CD ver} - {CD hor}	{CD left} – {CD right}	{CD left} – {CD right}	CD Through Pitch
Aberration Sensitivity	Astigmatism	Coma/Trifoil	Trifoil/Coma	Spherical

Aberration retrieval method

- Aberration retrieval using target images collected through focus and/or exposure dose in a partially coherent optical system
- Inverse imaging problem (numerical solution)
 - Use simulation/modeling for forward calculations to predict image shape in the image plane
 - Solve for match between reconstructed and measured image shape using numerical methods while varying Zernike coefficients
 - Iterative search algorithm to find aberration signature consistent with images throughfocus/dose


Extraction Flow

Stage 1

initial extraction

Stage 2

Iteration creating linear models using the previous iteration's outputs





Aberration Measurement First test case

- ASML AD1 (CNSE) λ =13.5nm, NA=0.25, σ =0.5
- Exposure and SEM data collected over the period of a month
- Film stack: Bare Si + ODL102 100 nm + SIARC SHB A940 35 nm +75 nm SEVR139 on four wafers
- Structures (repeated three times per field)
 - Astigmatism x (z5): P88 1:1 lines (reticle 1)
 - Astigmatism y (z6): P90 (45 degree) 1:1 lines (reticle 2)
 - Coma x (z7): P70 5-bar 1:1 (reticle 1)
 - Coma y (z8): rotated P70 5-bar 1:1 (reticle 1)
 - Spherical (z9): P75 P400 35nm CD trench (reticle 1)
 - Trefoil x (z10): 30nm T-brick wall bright field (reticle 1)
 - Trefoil y (z11): not available

Measured H-V CD Through Focus








P88 1:1 Horizontal and Vertical


Dose: 21 mJ/cm²

Focus start: -0.18um


Focus step: 0.01um



The change in the difference in CD between horizontal and vertical lines through focus can be correlated to the amount of x astigmatism in the system.




P90 1:1 45 degree lines




Dose: 21.5 mJ/cm²


Focus start: -0.21um

• Focus step: 0.02um




P90 1:1 45 Degree through focus






Coma X & Y



P70 1:1 5 Bar H (coma y)




P70 1:1 5 Bar V (coma x)

Dose Start: 22 mJ/cm² Dose Step: 1 mJ.cm² Focus start: -0.05um


 Left and right (top and bottom) CDs of a 5 bar structure were measured

Measured 5 Bar Data

Verticle 5 Bar, Coma X



Horizontal 5 Bar, Coma Y



Left/Right Delta CD ~ 2.5nm


Top/Bottom Delta CD ~ 5nm

The difference in CD of the left and right lines of the 5 bar structure matches well with the model, the CD is dependent on dose matching between the model and scanner.

*The extraction only uses the CD difference between left and right bars. This makes the metric somewhat CD independent.




Best focus through pitch



- 35nm trench through focus
- Center dose: 27 mJ/cm²
- Dose step: 1mJ/cm²
- Focus Center: -0.05um
- Focus Step: 0.03 um

Pitch (nm)	BF (um)	
400	-0.03	
300	-0.02	
250	-0.03	
200	-0.02	
150	0.02	
100	0	
75	-0.01	

35nm Trench through pitch






T – Bar Structure


• 30nm T-Bar

- Dose: 22mJ


Focus: -0.05um

Production






Extraction Flow



Stage 2 Details Extraction and user interface




Stage 2 Details Output

- Eight iterations took ~4 hours on 8 cores
- Zernike coefficients were extracted
 - Astigmatism X (-0.028 waves)
 - Astigmatism Y (0.014 waves)
 - Coma X (0.085 waves)
 - Coma Y (-0.044 waves)
 - Spherical (-0.006 waves)
 - Trefoil X (-0.185 waves)
- No Results for Trefoil Y

Aberration Measurement Second test case

- ASML AD1 (CNSE) λ =13.5nm, NA=0.25, σ =0.5
- Exposure and SEM data collected over the period of a few days
- Film stack: Bare Si + ODL102 100 nm + SIARC SHB A940 35 nm +75 nm SEVR139 on three wafers
- Structures (repeated three times per field)
 - Astigmatism x (z5): P80 1:1 lines (reticle 3)
 - Astigmatism y (z6): P80 (45 degree)1:1 lines (reticle 3)
 - Coma x (z7): P70 5-bar 1:1 (reticle 3)
 - Coma y (z8): rotated P70 5-bar 1:1 (reticle 3)
 - Spherical (z9): P64 P192 32nm CD line (reticle 3)
 - Trefoil x (z10): 30nm T-brick wall bright field (reticle 3)
 - Trefoil y (z11): rotated 30nm T-brick wall bright field (reticle 3)

Stage 2 Details Extraction and user interface




Stage 2 Details Output

- Eight iterations took ~4 hours on 8 cores
- Zernike coefficients were extracted
 - Astigmatism X (0.041 waves)
 - Astigmatism X (0.038 waves)
 - Coma X (0.050 waves)
 - Coma Y (-0.025 waves)
 - Spherical (0.044 waves)
 - Trefoil X (-0.209 waves)
 - Trefoil Y (-0.013 waves)

Comparing the two experiments

- Test target differences
 - Reticles
 - Target location on Reticle
 - Mask stack
 - Targets





- •Trefoil x (Z_{10}) is dominate aberration
- Collection time may influence results
- Reticles may have signature
- Field position varied

22

Summary

- A method was developed to measure and extract aberration levels using image based testing
 - Uses standard mask targets and few wafers
 - Iterative inverse wavefront solution in a multivariable environment
 - Interactive user interface
- Current efforts include more repeatability and predictability studies
- Targets that include phase structure (PSM) can add additional sensitivity and higher-order termsexperiments underway

Acknowledgments

- Lena Zavyalova
- KLA-Tencor for the use of PROLITH
- This work was performed by the Research Alliance Teams at various IBM research and development facilities
- SRC/ GRC and US Dept. of Education for their support of this project









References

- ¹ L. Zavyalova, et al, in *Proceedings of SPIE* (San Jose, CA, USA, 2004), **5377**, pp. 1728-1737.
- ² L. Foucault, C. R. Acad. Sci. **47**, 958ff (1858).
- ³ W.P. Linnik, Proc. Academy of Sci. of the USSR 1, 208 (1933).
- ⁴ H. Medecki, E. Tejnil, K.A. Goldberg, and J. Bokor, Opt. Lett. **21**, 1526 (1996).
- ⁵ P.P. Naulleau, K.A. Goldberg, and J. Bokor, J. Vac. Sci. Technol. B **18**, 2939 (2000).
- ⁶ C.G. Krautschik, et al, in *Proceedings of SPIE* (Santa Clara, CA, USA, 2001), **4346**, pp. 524-534.
- ⁷ A. Abdo, B. La Fontaine, and R. Engelstad, J. Vac. Sci. Technol. B **21**, 3037 (2003).
- ⁸ J.P. Kirk, in *Proceedings of SPIE* (Santa Clara, CA, USA, 2000), **4000**,pp. 2-8.
- ⁹ K. van Ingen Schenau, et al, in *Proceedings of SPIE*(Santa Clara, CA, USA, 2002), **4691**,pp. 637-651.
- ¹⁰ P. Dirksen, et al, in *Proceedings of SPIE* (Santa Clara, CA, USA, 2000), **4000**, pp. 9-17.
- ¹¹ H. Nomura and T. Sato, Appl. Opt. **38**, 2800 (1999).