


# EUVL mask repair: expanding options with nanomachining

Gregory McIntyre<sup>1</sup>, Emily Gallagher<sup>2</sup>, Mark Lawliss<sup>2</sup>, Tod Robinson<sup>3</sup>, Jeffrey LeClaire<sup>3</sup>, Ron Bozak<sup>3</sup>, Roy White<sup>3</sup>

<sup>1</sup> IBM Microelectronics, 257 Fuller Road, Albany, NY 12203, USA

<sup>2</sup> IBM Microelectronics, 1000 River St, Essex Junction, VT 05452 USA

<sup>3</sup> RAVE LLC, 430 S. Congress Avenue, Suite 7, Delray Beach, FL 33445, USA




# Outline

**Purpose:** Introduce method to repair both the phase and amplitude effects of a multi-layer bump defect

- Multi-layer (ML) defect review
  - Review of mitigation/compensation strategies
- Phase repair
- AFM – options for nanomachining defects
- Experimental results
  - Clear area repairs
  - Line-space repairs
- Putting it all together: ML defect repair with AFM
- Conclusions

# Multilayer bump defect

- Multilayer defects are unlikely to be eliminated completely from blanks
- ML defects create both phase and amplitude effects






Substrate defect

Bossung Tilt = Phase effect


CD error = Amplitude effect

## Simulated Images Through Focus




# Strategies for mitigating impact of ML defects

- Pattern shift




*E. Gallagher, et al.,  
EUVL Symposium 2011.*

- Repair defects before absorber deposition



*P. B. Mirkarimi et al., J.  
Appl. Phys. 91, 81  
(2002).*

- Absorber compensation




*L. Pang et al., Proc. of  
SPIE Vol. 8166, 2011.*

- Phase repair + absorber compensation


(Topic of this presentation)

# Absorber-only compensation example



- 28nm HP, ML defect with 2nm bump height (47nm FWHM) centered in space
- Simple absorber bias compensates amplitude effect
- Little impact on phase effect (asymmetric behavior through focus remains)



Side view




Top-down




# Phase compensation with ML repair


- Creation of pit at top of ML to counteract phase effect of bump defect
- Bossung tilt is corrected; absorber bias still required






# Phase compensation with ML repair

- Vary repair dimensions (28nm HP example with 2nm bump height & 47nm FWHM)
- Multiple combinations of width and depth can be selected
  - Depth is 30-90nm (depending on ML bump defect height)
  - Width is roughly FWHM of ML defect
- Other shapes can be used (i.e. )



# Nanomachining process

- Merlin® nanomachining removes material without etch stops, heat or gases in 3 steps
  - Step 1: non-contact AFM scan of defect and reference structures to the nanometer level
  - Step 2: contact mode removes material using cold mechanical processes (NanoBit®)
  - Step 3: particulate debris is removed using EcoSnow, BitClean®, wet cleaning, etc.







# Options for nanomaching defects

- Multilayer material removal
  - Remove multilayer material to precise depths and widths to create a phase change
- Opaque removal
  - Remove extra material to restore design
  - Compensate for amplitude effect of defect and phase repair

**Multilayer material removal**



**Ta-based absorber edge repair**




# Outline

**Purpose:** Introduce method to repair both the phase and amplitude of a multi-layer bump defect

- Multi-layer (ML) defect review
  - Review of mitigation/compensation strategies
- Phase repair
- AFM – options for nanomachining defects
- Experimental results
  - Clear area repairs
  - Line-space repairs
- Putting it all together: ML defect repair with AFM
- Conclusions

# Experimental Work


- Goal of initial experimental work is to verify “repair-only” behaves as predicted by simulation
- Good match suggests feasibility to determine required repair via modeling




# Experimental results: clear area “repair” example

- Nanomachined a 70nm square, ~69nm deep “repair” on an EUVL mask multilayer surface
- Imaged on Actinic Inspection Tool (AIT) – EUV microscope
  - Phase response through focus similar to simulation of AFM topography
  - Some amplitude offset observed


## AFM Scan




## Images through focus



## Intensity vs. position




## Simulate AFM topography





# Experimental results: clear area “repair” example

- Analysis of 5 repair sizes (depth varies between 16 and 69 nm)
- Strength of phase response ( $\Delta\text{Intensity} / \Delta\text{Focus}$ ) similar to simulation of AFM topography
- Good match suggests ability to determine required ML defect repair with simulation





Phase response =  $\Delta\text{Intensity} / \Delta\text{Focus}$




# Experimental results: 32nm HP line-space “repairs”

- Simulation of AFM topography predicts Bossung tilt




AFM (50nm deep “repair”)



Through focus response of multilayer “repair”



Simulation of AFM topography







# Experimental results: 32nm HP line-space “repairs”

- AIT Imaging results closely match tilt predicted by simulation

AFM (50nm deep “repair”)





Through focus response of multilayer “repair”



Reference



“repair”

AIT




- Iso-focal Bossung slopes both very close to 4nm  $\Delta$ CD in  $\pm 50$ nm defocus

Simulation





# Experimental results: 28nm HP “repairs”

- 3 Sites of varying “repair” depth analyzed (32, 48 & 70nm deep)
- AIT data confirms expected tilt of Bossungs
- Reasonable match to simulation of AFM topography




# Putting it all together: ML defect repair

- Repair process
  - Characterize defect (imaging, AFM)
  - Model defect
  - Model required repair dimensions
  - Repair phase + absorber compensation
  - Verify & fine tune
- Example of real mask repair with simulated defect:
  - 82nm deep “repair” & BitClean®
  - 50nm HP lines (note: successful nanomachining demonstrated down to 22nm HP lines)
  - Place repair over simulated off-center defect



# Putting it all together: ML defect repair


- Phase repair restores the Bossung tilt
- Absorber repair restores target print CD



Reference

ML defect only

Phase repair only


defect + phase  
repairdefect + phase  
repair + absorber  
biasdefect + absorber  
bias only

# Summary


- Multilayer defects have both amplitude and phase effects
  - A complete multilayer repair addresses both
- Nanomachining provides new ML defect repair capabilities
  - Multilayer to adjust phase
  - Absorber to change amplitude
- Achieved good agreement between simulation and AIT data
  - Isolated pits created in clear multilayer
  - Line/space patterns in geometries down to 28nm HP
- This is a proof of concept. Various areas to be investigated prior to manufacturing implementation

# Future work

- Lifetime and durability at repair site needs to be addressed
  - Simulation suggests thin passivation layer would not harm optical effect of repair



- This work focused on bump defects. Similar effect can be achieved for pit defects by depositing material (i.e. bossings tilted the other way)
- In process of testing concept on ML defect test mask
- Repair specifications and tolerances to be determined
  - Experimental repair work suggests nanomachining can meet specifications
  - Simulation suggests reasonable tolerances
- Reasonable speed and accuracy of computational models required for manufacturing implementation
- AIMS tool could be required for practical implementation





# Acknowledgments

- IBM's mask house engineering and manufacturing teams for mask builds and processing
- Sematech for Actinic Inspection Tool (AIT) time
- Kenneth Goldberg (CXRO), Iacopo Mochi (CXRO), for AIT support and insight