


# Development of DSA Approaches for Healing of LER and Shrinking of CD that are Compatible with Standard EUV Resists





## A/Prof. Idriss Blakey i.blakey@uq.edu.au

#### Co-authors/collaborators

- Dr Anguang Yu (UQ)
- Dr Imelda Keen (UQ)
- Dr Elliot Cheng (UQ, now ANFF)
- Ms Yami Chuang (UQ)
- Dr Kevin Jack (UQ, CMM)
- Dr Michael Leeson (Intel)
- Dr Todd Younkin (Intel)
- Prof. Andrew Whittaker

**Funding** 





Australian Government
Australian Research Council

**Facilities** 

Australian National Fabrication Facility (ANFF)

- Lauren Butler
- Flana Taran

**Australian Synchrotron** 

Centre for Microscopy and Microanalysis (CMM)

Centre for Advanced Imaging


Australian Institute for Bioengineering and Nanotechnology


### **Motivation and Aims**

- Despite significant improvements, the ability to simultaneously achieve ITRS targets for resolution, sensitivity and LER remains elusive.
  - A number of resists can now achieve the resolution and sensitivity targets, but fall short when it comes to LER.
- UQ's Aim: To develop directed self assembly (DSA) materials and processes that can heal the LER of EUVL resists.



### Block Copolymer (BCP) Healing of LER







### Why PS-b-PDLA?

- PS-b-PDLA has favourable thermodynamic properties.
  - $-\chi(298 \text{ K}) = 0.217 0.233^{-1}$ 
    - Domain sizes of  $< 8 \text{ nm (pitch/}L_0 < 16 \text{ nm)}$  are theoretically possible.
  - $T_g$  values are below  $T_g$  values of most resist polymers.
  - PDLA block is easily degraded by hydrolysis.


 Ohnishi parameters predict and our experiments show that PS block has a higher etch resistance than PLA.

ВСР	$\chi_{AB}$
PS-b-PMMA	0.041
PS-b-PDLA	0.217

Bigger  $\chi$  is better




### Synthesis of PS-b-PDLA



Polymer Size Analysis

14.7 k


6.9 k




MW	vol % PDLA	PDI	χN	Bulk L <sub>0</sub> by SAXS (nm)	Bulk domain size by SAXS (nm)
12.0k	50	1.25	30.6	15.9	8.0
14.7k	48	1.14	37.0	16.5	8.3
16.5k	46	1.18	42.1	19.8	9.9
21.0k	48	1.25	53.6	21.3	10.7

We have also developed variants that should be able to achieve smaller feature sizes (i.e. Predicted to have higher  $\chi$  parameters).

### **EBL** Patterning




### Patterning Results



- PAB 95 °C, PEB 105 °C.
- Dose =
  - ~16 mJ/cm<sup>2</sup> (EUVL).
  - $\sim$ 40 µC/cm<sup>2</sup> (20 kV EBL).
- LER = 4 7 nm.



### DSA - BCP Deposition and Annealing



Solvent for deposition of BCP is a non-solvent for the resist.


Polystyrene – *b* – poly(DL-lactide) or PS-b-PDLA

Annealing temperature = 100 °C

- Lower than  $T_q$  of resist (123 °C)
- Much lower than annealing temperature required for PS-b-PMMA (>180 °C)



### Dry Etch of BCP



OF QUEENSLAND


AUSTRALIA

Etch Rate (nm/s)				
	20 W,			
Polymer	5 sccm Ar			
	30 s etch			
PS	0.93			
PDLA	3.6			
PMMA	2.3			

Selectivity			
	20 W,		
Polymer	5 sccm Ar		
	30 s etch		
PS	1		
PDLA	4		
PMMA	2.5		


Selectivity 1.6 x higher than PS-b-PMMA

### DSA Results ( $4 \times$ Pattern Multiplication, $4L_0$ )






### DSA Results ( $6L_0$ , $7L_0$ )







Time: 30 s

### DSA Results (2 $L_0$ )



### **LER Analysis**






Threshold	CD (nm)	LER (nm)
0.75	45.4	11.0
0.64	51.5	10.6
0.48	63.7	9.0
0.39	71.8	8.1
0.30	79.3	7.6
0.23	84.1	8.3



30% reduction in LER observed

### LER analysis - PSD

Comparison of LER PSD of Resist and BCP in 2L<sub>0</sub> Trench




- PSD is significantly lower at lower frequency ranges (~1/70 nm<sup>-1</sup> to 1/333 nm<sup>-1</sup>)
- Converges at a spatial frequency of ~1/6 nm<sup>-1</sup>



### Concept 2


### Overview of Methodology



- 1) Sidewalls of non-CAR resists are typically negatively charged.
- 2) Allows attachment of positively charged block copolymers.
- 3) Annealing at temperatures above  $T_g$  of non-charged block allows polymer to re-arrange to reduce LER.




### Preparation of block copolymer




- Use controlled polymerization (RAFT) so get controlled size  $(M_n)$  and dispersity of size (PDI).
- Design philosophy
- PDMAEMA imparts charge and water solubility.
- PtBuMA: intermediate  $T_g$  facilitates healing structures annealing and is hydrophobic to drive self assembly of nanostructures in water.

#### Control of size





### Block copolymer self assembly in water



• Charge of BCP is *pH* dependent and plateaus at pH values < 6.5

AUSTRALIA


• At this *pH* 6.3, the cryo-TEM shows the BCP forms polymersomes (vesicles).


### Adhesion to negatively charged surfaces


#### **AFM analysis**


XPS analysis (N 1s)















 Adhesion of positively charged polymersomes onto negatively charged surfaces is confirmed.



### Effect of annealing



- AFM Decrease of surface roughness with increasing temperature.
  - BCP rearranges → smoother surfaces driven by minimization of surface tension.
- GISAXS Bragg rods are consistent with deposition of vesicles.
  - Loss of these features during annealing are also consistent with surface restructuring and smoothing.


The University

AUSTRALIA

19

### Preparation of model rough surface

#### **Top Layer**



56 mol%: 44 mol%


1 wt% in anisole + PAG

#### **Bottom Layer**

60 mol%: 20 mol%: 20 mol%

10 wt% in EL + 0.07 wt% quencher

Prabhu, V.M., et al., Advanced Materials, 2010




Schematic was reproduced from Prabhu, V.M., et al., Advanced Materials, 2010

- Bilayer films were prepared with PAG in the top layer, but not in the bottom layer.
- Upon illumination a strong acid will be produced, which diffuses vertically to the bottom layer during PEB.
- This method creates a surface with similar roughness chemistry to the side wall of resist features.




### Annealing on model rough surface



- Roughness was smoothed (healed) upon annealing (from RMS 2.5 to 0.7 nm).
- The annealing temperature  $> T_g$  of the BCP, but less than the resist.
- 70% decrease in RMS roughness.


### Healing of Patterned Features




- LER before coating 5.8 nm.
- Dip-coating with polymersomes solution shows a decrease in CD, but LER remains similar.
- Annealed polymersomes on patterned surface can reduce LER from
  5.8 nm to 3.4 nm (41 % decrease).



### BCP mediated LER Smoothing - PSD





LER: 3.4 nm ± 0.3 nm


Smoothing observed over all frequency ranges.





### 2nd Gen BCPs for Healing

- 1<sup>st</sup> generation BCPs had a diameter of ~19 nm.
  - Obviously not ideal for healing small features (<40 nm).</li>
- 2<sup>nd</sup> generation BCPs aim to decrease size of particles (target < 6 nm)</li>

EUVL Patterned Resist – Thanks to Michael Leeson @ Intel. PHOST based resist










### Conclusions/Summary

- 1. PS-b-PDLA block copolymers are capable of assembling into patterned resists to give half pitch CD as small as 8.0 nm.
  - Polymers with smaller domain sizes are being investigated.
  - $T_q$  of BCP is lower than for typical resist polymers
    - no hardening of resist required.
  - Coating solvent is a non-solvent for a PHOST based resist.
  - Trench shrink of 66% 48 nm → 16 nm.
  - LER reduction ~30%.
- 2. Treatment with Aqueous solutions of BCP lead to substantially improved LER and have potential for general use.
  - Champion LER decrease in model rough surface 70%
  - Champion LER decrease in patterned features 41%





# Development of DSA Approaches for Healing of LER and Shrinking of CD that are Compatible with Standard EUV Resists





## A/Prof. Idriss Blakey i.blakey@uq.edu.au

#### **Co-authors/collaborators**

- Dr Anguang Yu (UQ)
- Dr Imelda Keen (UQ)
- Dr Elliot Cheng (UQ, now ANFF)
- Ms Yami Chuang (UQ)
- Dr Kevin Jack (UQ, CMM)
- Dr Michael Leeson (Intel)
- Dr Todd Younkin (Intel)
- Prof. Andrew Whittaker

**Funding** 





Australian Government
Australian Research Council

**Facilities** 

Australian National Fabrication Facility (ANFF)

- Lauren Butler
- Flana Taran

**Australian Synchrotron** 

Centre for Microscopy and Microanalysis (CMM)

Centre for Advanced Imaging

Australian Institute for Bioengineering and Nanotechnology