

# Sn Etching With Hydrogen Plasma

John Sporre<sup>1</sup>, Jason Peck<sup>1</sup>, Tae S. Cho<sup>1</sup>, David N. Ruzic<sup>1</sup>,  
Shailendra N. Srivastava<sup>2</sup>, David C. Brandt<sup>2</sup>

<sup>1</sup>Center for Plasma-Material Interactions

<sup>2</sup>Cymer, Inc.



ILLINOIS  
UNIVERSITY OF ILLINOIS AT URBANA-CHAMPAIGN

---

Nuclear, Plasma, and Radiological Engineering  
Center for Plasma-Material Interactions

---

Contact: [druzic@illinois.edu](mailto:druzic@illinois.edu)



- **Introduction**
- **Sn Film Growth**
- **Hydrogen Cleaning Process**
- **Experimental Setup**
- **Results and Discussion**
- **Conclusion**



# Introduction


- Sn deposition on EUV collector optics cripples reflectivity with just a couple nanometers of deposition.
- Thermal evaporation is not a solution, high energy ion sputtering is not a solution. Other methods required.
  - High temperature would result in multilayer diffusion.
  - Sputter will remove multilayers as well as the Sn.
- One possible solution is the use of **hydrogen plasma** to create volatile  $\text{SnH}_4$  to remove Sn from the surface of the collector.
- The effects of pressure, flow rate, surface size on Sn *removal rates* are examined.



- Introduction
- **Sn Film Growth**
- Hydrogen Cleaning Process
- Experimental Setup
- Results and Discussion
- Conclusion





- Sn comes from the condensable fuel used in creating EUV light.




# Sn Film Growth


- Sn growth depends on adatom-surface interaction.
- Sn-Si and Sn-Ru growth exhibits **Stranski-Krastanov** growth: 1-2 ML of coverage with additional island growth.



- Sn-Sn:Sn-Si  $\rightarrow$  1.35
- 19.5% mismatch resides slightly within SK growth<sup>1</sup>
- Variations in deposition parameters can affect how Sn is grown.





Thermal Deposition  
 $T < 0.1$  eV



Energetic Deposition  
 $T \sim 2-10$  eV

1) Summary Abstract: Interface formation in IV-IV heterostructures: Tin on silicon  
M. Zinke-Allmang, H.-J. Gossmann, L. C. Feldman, and G. J. Fisanick, J. Vac. Sci. Technol. A 5, 2030 (1987),  
DOI:10.1116/1.574912

- Energetic sputtering of deposited Sn by non-mitigated EUV plasma species is insufficient below 400 eV.



- Introduction
- Sn Film Growth
- **Hydrogen Cleaning Process**
- Experimental Setup
- Results and Discussion
- Conclusion







# Hydrogen Plasma Vs. Atomic Hydrogen Source<sup>9</sup>

- ~10x Higher Sn removal rates with H<sub>2</sub> plasma source versus atomic H\* source in same tool configuration
- Increased uniformity
  - Plasma is a uniform radical source across the Sn removal plane
    - Located above Sn contamination
    - Radicals readily created within proximal distance of Sn contamination.
  - Atomic hydrogen sources are point sources
    - 1/r<sup>2</sup> flux drop off
    - Relies on long distance diffusion

**H<sub>2</sub> Plasma Source**




**Atomic H\* Source**




# How Hydrogen Plasma Cleans

- ~~At the beginning of the process, the surface is covered with contaminants (e.g.,  $\text{SiO}_2$ ).~~  
~~Molecular species are generated and diffuse toward the surface.~~  
 diffuse toward the surface.



- This  $\text{Si}_4$  can deposit on the collector.




- Introduction
- Sn Film Growth
- Hydrogen Cleaning Process
- **Experimental Setup**
- Results and Discussion
- Conclusion





# Experimental Setup

- Large stainless steel plate (16 cm wide) attached to a 13.56 MHz, 500 W max RF-generator. Samples etched 20 min.
- Pressures explored at 100 sccm for 80, 300, 500, 1000 mTorr using a gate valve to adjust pump rate.
- Flow rates of 50, 100, 500, 950 sccm explored at 80 mTorr.
- Masked, Sn coated Si witness plates located at three different locations from the center of the RF-antenna plate: 5 cm, 9 cm, 13 cm



# Experimental Setup

- RF-antenna installed in CPMI's XTS 13-35 source chamber to allow pressure/flow rate manipulation with adequate chamber size.
- Langmuir triple probes are utilized to measure plasma parameters at positions 1-3.
- Electron-beam evaporation utilized to coat Sn samples up to 300 nm.



- Introduction
- Sn Film Growth
- Hydrogen Cleaning Process
- Experimental Setup
- **Results and Discussion**
- Conclusion




# Effect of Sample Size

- Small sample etches ~ 7x faster than larger sample
- Unable to etch large sample at same conditions. Why?  
**Redeposition**
- Higher flow rates required to remove  $\text{SnH}_4$  from sample.


## 1 cm Width Sample

25 sccm 100 mTorr 2000W RF



## 12.5 cm Width Sample

75 sccm 100 mTorr 2000W RF







# Etch Rate Vs. Pressure (100 sccm)

- Etch rate maximized at lowest pressure.
- More likely to redeposit at higher pressures.
- Sample location 2 (furthest from open space) has lowest average Sn removal rate observed.

## Locational Removal Rate




## Average Removal Rate




# Etch Rate Vs Flow Rate

- Less than 500 sccm, too little flow rate. Above 500 sccm too few radicals.
- 950 sccm flow rate minimizes cross-antenna variation at a cost in removal rate.

## Locational Removal Rate




## Average Removal Rate




# Plasma Parameters Vs. Pressure (100 sccm) <sup>19</sup>

- Increasing chamber pressure results in increasing electron temperature.
- Temperatures appear high and might be the result of beams, which are not perceivable with triple probes.
- Electron density appears independent of pressure.

## Electron Temperature




## Electron Density




# Plasma Parameters Vs. Flow Rate (80 mTorr)<sup>20</sup>

- Electron temperature appears independent of chamber flow rate.
- Electron density is relatively uniform except at 950 sccm where it increases by nearly a factor of 2.

## Electron Temperature





## Electron Density





# Recap

- Increased radical production at higher pressure
  - Should increase *etch rate*, but *removal rate* doesn't agree.
- Increased pressure, increases  $\text{SnH}_4$  decomposition.



# Recap

- $\text{SnH}_4$  removal increases with increasing flow rate
- $\text{H}^*$  not largely removed until very high flow rates



Best scenario for cleaning is low pressure and the appropriate flow rate.

- Introduction
- Sn Film Growth
- Hydrogen Cleaning Process
- Experimental Setup
- Results and Discussion
- **Conclusion**



# Conclusions

- It is possible to remove Sn from a collector optic using an in-situ H<sub>2</sub> plasma cleaning system.
- The decomposition of unstable SnH<sub>4</sub> makes removing Sn from large surfaces difficult but not impossible. Sn removal rate  $\neq$  Sn etch rate.
- Higher flow rates are required to remove SnH<sub>4</sub> from larger samples before it decomposes.
- Under presented experimental conditions, optimal Sn removal from large surfaces occurred at 500 sccm, 100 mTorr, 500 W RF power. Net removal rates as high as **7.5  $\pm$  0.5 nm/min**.
- Net Sn removal rate less affected by variations in pressure/plasma conditions than by flow rate.




- Special thanks to Cymer, Inc. for funding this research.
- Special thanks to Intel, inc., SEMATECH, inc., and Xtreme Technologies, GmbH for providing the XTS 13-35 source.
- Part of this work was carried out in part in the Frederick Seitz Materials Research Laboratory Central Facilities, University of Illinois, which is partially supported by the U.S. Department of Energy under grants DEFG02-07ER46453 and DE-FG02-07ER46471.

# Thank You For Your Attention!



# Sample Size Etch Difference

1 cm<sup>2</sup> Sample Size: Magnetron



125 mm Sample Size: Magnetron

