




Accelerating the next technology revolution

# Level-specific material evaluations for NXE3300 applications

Karen Petrillo, Cecilia Montgomery, Kyoungyong Cho, Alexander Friz, Yu-Jen Fan, Chandra Sarma, Dominic Ashworth, Mark Neisser, Takashi Saito, Lior Huli, Shannon Dunn




# Agenda



- Introduction
- Line/space applications
  - Exposure tool: Albany MET with bi-convex dipole
- Contact and via applications
  - Exposure tool: ADT
- 2D imaging
  - Exposure tool: Albany MET with quadrupole illumination
- LWR and pattern collapse improvement
  - Exposure tool: ADT
- Defect reduction
  - Exposure tool: ADT
- Summary


# Normalized Image log slope

## Berkeley MET





Central obscuration on objective lens: 2-beam imaging: pseudo PSM


## Albany MET




Biconvex dipole(sigma =0.55/0.9) Quadrupole=0.36/0.93)



Quadrupole : 14L28P



Biconvex dipole : 14L28P




Berkeley Exposure: 14L28P

For 14nm L/S or below, Biconvex or Pseudo PSM is needed.

# Z Value of EUV resists over time

(for lines and spaces)





	Resolution	LER(LWR)	Sensitivity	Z-factor	Comment
MPU Gate 21nm	21nm	1.27(1.8) nm	10mJ/cm2	1.5E-09	These number from ITRS
Z-factor	16nm	1.41(2.0) nm	10mJ/cm2	8.0E-10	These target from SMT MC for 2014







- Data represents materials from six suppliers
- Mostly improvement in Z value comes from improving the aerial image
- Some progress in Z value due to the resist improvements is evident
- Data here is not exactly comparable to ITRS roadmap values due to differences in half pitch and LER measurement details

- **Line/space**
  - **Exposure tool: Albany MET with bi-convex dipole illumination**
- Contact and via on ADT
- 2D imaging
- LWR and pattern collapse improvement
- Defect reduction

# 16 nm hp with bi-convex dipole



Old illuminator  
0.36/0.68 dipole




New illuminator  
0.55/0.93 dipole



16 nm hp imaging capability has been achieved using bi-convex dipole




# Recommended illumination settings



- Quadrapole (0.36/0.93)
  - CH and L/S 50 nm – 20 nm
- Bi-convex dipole (0.55/0.93)
  - L/S 20 nm and below

# Process Improvements: Resist N

## 18nm Half-Pitch, Bi-Convex Dipole Illumination










- Control condition with TMAH developer has significant “matting”
- Small improvement with TMAH developer and topcoat, and TBAH developer and topcoat
- Significant improvement with the combination of TBAH/FIRM™/Topcoat



# Process Improvements with Resist O

## 18nm Half-Pitch, Bi-Convex Dipole Illumination



	Control	FIRM™ Extreme™ 10	FIRM™ Extreme™ 12	FIRM™ Extreme™ 10 / Top Coat
TMAH				
TBAH				

- TMAH, with and without FIRM has significant “matting”
- Topcoat improves imaging with both TMAH and TBAH developer

# Agenda






- Line/space with bi-convex dipole
- **Contact and via**
  - **Imaging comparison on LBNL MET tool**
  - **Exposure tool for detailed evaluation: ADT**
- 2D imaging
- LWR and pattern collapse improvement
- Defect reduction

# Contact hole imaging

- Issues
  - Sensitivity
  - Local CDU
  - Circularity
  - Contact edge roughness
- Possible Causes
  - Shortage of EUV photons
  - Shot noise
  - MEEF
  - Stochastics

## Mitigation Strategies


- Biased reticle
  - Sensitivity improvement
  - Local CDU improvement
  - Resolution improvement
- Post-process techniques
  - Improves contact edge roughness (CER)



# Contact Hole imaging on the LBNL MET tool



Berkeley MET  
Quad, NA 0.3, sigma 0.48~0.68  
FT 80nm  
Underlayers  
No mask bias



\* CDU was measured at 26nm HP


	28nm	26nm	24nm	23nm	22nm	21nm	20nm
A							59.5mJ/cm² 2.5nm
B							52.4mJ/cm² 2.4nm
C							36.3mJ/cm² 3.3nm
D							35.0mJ/cm² 3.2nm
E							19.8mJ/cm² 3.1nm
F							23.9mJ/cm² 3.0nm

Dose size [mJ/cm²] / LWR [nm]


# Resist P Contact Hole Variability, 32nm



Local CDU



Circularity




4, 8, and 12nm Bias are significantly better for local CDU, circularity, and variability of circularity


# Lithographic Comparison for 3 resists




## Resist P



## Resist N












## Resist S



- Local CDU:
  - Resist P has improved local CDU with bias of  $\geq 4$
  - Bias8 looks appropriate for Resist N.
- Circularity is similar on all resists
- Photospeed improves with bias for all resists




# Image comparison of 3 resists

	Resist P	Resist N	Resist S
Image Mask Bias: 8nm Focus: 0um			
Dose size	29 mJ	25 mJ	12 mJ
Image Mask Bias: 4nm Focus: 0um			
Dose size	38 mJ	31 mJ	16 mJ
Image Mask Bias: 0nm Focus: 0um			
Dose size	62 mJ	32 mJ	21 mJ

- Resist P has best local CDU, at the expense of photospeed.
- Resist N has intermediate photospeed and similar CDU to resist P
- Resist S has the best photospeed, but at the expense of local CDU

# Process window for resist N



8 and 12 nm biases



- Process window needs to be taken into account when choosing correct bias
  - DOF is similar at 10% EL
  - 8 nm bias has larger total DOF



# TEL Contact Smoothing Data, Resist P




- Smoothing and FIRM rinse are verified to contribute CER improvement for contact hole feature.

# Agenda



- Line/space with bi-convex dipole
- Contact and via on ADT
- **2D imaging**
  - **Imaging comparison on LBNL MET tool**
  - **Exposure tool for detailed evaluation: Albany MET**
- LWR and pattern collapse improvement
- Defect reduction


# High resolution materials (based on LBNL exposures)




- Z factor is  $5.2e-9$  for Q
- Z factor is  $6.5e-9$  for R
- Both materials have high performance for L/S applications
- Evaluated for line end performance

# Material performance for 2-D imaging


30nm




Line end



30nm



Space end



Line and space end performance is an attribute that needs further improvement

# Agenda



- Line/space with bi-convex dipole
- Contact and via applications
- 2D imaging
- **LWR and pattern collapse improvement**
  - **Exposure tool: ADT and Albany MET**
- Defect reduction


# Pattern Collapse Margin with FIRM Rinse



## <Over Dose Line Pattern Collapse Margin at 26nmhp>

	Dose [mJ/cm <sup>2</sup> ]	13.00	14.00	15.00	16.00	17.00	18.00
	Image						
w/o FIRM							
	Image						
Extreme10	Dose [mJ/cm <sup>2</sup> ]	12.65	13.70	14.75	15.80	16.85	17.90
	Image						
Extreme12	Dose [mJ/cm <sup>2</sup> ]	12.20	13.30	14.40	15.50	16.60	
	Image						

## <One way ANOVA>




- Extreme™ 10 and 12 show improvement of line pattern collapse margin from w/o FIRM.
- LWR can be improved by 6-9% using FIRM rinse.

Albany MET

# Process Window for Resist T with FIRM Rinse



## <Comparison of PW by w/o FIRM and w/ FIRM>




	DOF at 8% EL [nm]	Improved [%]
w/o FIRM	117	-
Extreme10	348	222%
Extreme12	331	211%

- Extreme<sup>TM</sup> 10 and 12 improved process margin, which at 8% EL is over 300nm of DOF.

# Thru-Etch Test w/ Organic BARC



- Experiments Process Flow




\* Track full combination process:  
Developer optimization + FIRM rinse + Smoothing process

《Process condition》  
Resist: SEMATECH POR  
Resist  
Film thickness: 75nm  
Mask CD: 32nm Line 1:1  
DEV: TMAH



# Thru-Etch Test Result



- Both Stack-A and B full combination process show over 28% improvement.
- Stack-B full combination process delivers best LWR improvement 34%.
- w/ BARC process gives better improvement for Etch smoothing.

# Agenda



- Line/space with bi-convex dipole
- Contact and via on ADT
- 2D imaging
- LWR and pattern collapse improvement
- **Defect reduction**
  - **Exposure tool: ADT**

# TEL Defect data from KLA2835





- Resist N

## MGP TMAH w/ Extreme™ 10

(Resist N on Tri-layer stack)

- Defect: 43 [counts]
- Defect Density: 0.55 [count/cm<sup>2</sup>]



BP : Bridge Pattern  
FM : Foreign Material  
EC : Embedded Contamination  
MP : Missing Pattern  
PB : Partial Bridge Pattern  
ST : Stain Defect  
NV : Non Visible

- D.D. 0.55 count/cm<sup>2</sup> had achieved with high sensitive measurement

# Summary



- High resolution imaging can be improved using bi-convex dipole illumination by applying FIRM techniques combined with alternate developer and topcoat
- Contact hole printing is hampered by local CDU and circularity
  - Both can be improved using the appropriate reticle bias
  - Contact edge roughness can be improved by smoothing
- 2D imaging needs to be studied more thoroughly
  - Even the most promising materials require better tip-to-tip performance
- LWR and pattern collapse are improved with track-based post-processing
  - LWR improves by ~34% with FIRM, smoothing, and etch-based techniques
  - FIRM Extreme™ 10 & 12 both improve the collapse margin and resist T process
- Defects are monitored continuously; they are primarily bridging, foreign material, and embedded contamination

# Acknowledgements



- RMDC team
- LBNL staff
- Matt Colburn

