

An abstract, flowing purple graphic in the top-left corner, resembling a stylized flame or a dynamic liquid splash, with various shades of purple and magenta.

DSA AS A COMPLEMENTARY TECHNIQUE FOR CONTACT HOLE PATTERNING

ROEL GRONHEID, ARJUN SINGH, JOOST BEKAERT, TODD YOUNKIN*, SAFAK SAYAN*,
NADIA VANDENBROECK, BOON TEIK CHAN, **GEERT VANDENBERGHE**

* INTEL ASSIGNEE AT IMEC




SCOPE OF THIS TALK

DSA and EUV:
competing, complementing, enabling ?



Use case:

Contact holes patterning using ArFi/EUV
pre-patterns followed by a DSA process.


WHAT IS 'DIRECTED SELF ASSEMBLY' ?



+




Chemo-epitaxy




Grapho-epitaxy

SELF-ASSEMBLY OF BLOCK COPOLYMERS IN THE BULK

Block Copolymers are macromolecules formed by two or more chemically distinct polymer chains joined by a covalent bond



Poly(styrene-*b*-methyl methacrylate)



Structures represent thermodynamic minima
Dense features - 3 to 50 nm length scale
How to control 'preferred' feature type, size and pitch ?


SELF-ASSEMBLY OF BLOCK COPOLYMERS IN THE BULK

BCP: A and B in separate segments




n/m determines phase

- Lamellar for LS
- Cylinders for CH




$n+m$ determines

- pitch (and CD)



Feature, CD and pitch are in the bottle – ‘Brain in the bottle’, ©Ralph Dammel

FEATURE TYPE AND CD IN THE BOTTLE FREQUENCY ANALYSIS



Frequency analysis on self-assembled BCP material allows to determine L_0 and check phase separation quality.

OUTLINE




Introduction

Contact Hole Shrink (grapho-epitaxy)

Templated Process (grapho-epitaxy)

Honeycomb Process (chemo-epitaxy)

Summary




OUTLINE

Introduction

Contact Hole Shrink (grapho-epitaxy)

- ▶ Homopolymer blend and block co-polymer
- ▶ Demonstration of electrical functionality







Templated Process (grapho-epitaxy)

Honeycomb Process (chemo-epitaxy)

Summary



TWO DSA OPTIONS TO COMPARE

POLYMER BLEND & PS-PMMA BCP

	Blend type (PolymerA/PolymerB)	BCP type (PS- <i>b</i> -PMMA)
Polymer phase separation	 <ul style="list-style-type: none"> No specific dimension, morphology, or periodicity 	 <ul style="list-style-type: none"> Intrinsic dimension and pre-determined morphology
CH Shrink	 <ul style="list-style-type: none"> Polar polymer remains for pattern shrink and less polar polymer is removed 	 <ul style="list-style-type: none"> PS remains for pattern shrink and PMMA is removed
Development	<ul style="list-style-type: none"> Organic solvent 	<ul style="list-style-type: none"> Dry development UV irradiation with polar solvent
Anneal condition	<ul style="list-style-type: none"> 120 -150 °C 	<ul style="list-style-type: none"> 200 -250 °C

EVEREST28 ELECTRICAL TEST VEHICLE


LI2-VA0-MTI SHORT LOOP



Want to leverage IMEC's existing 28 nm node infrastructure in order to electrically test VA0 layers built with C/H DSA.


EVEREST28 ELECTRICAL TEST VEHICLE

VA0 STACK, DSA, & PATTERN TRANSFER BASED ON IMEC STD PROCESS




INTEGRATED PROCESS LOOKS GOOD

POLYMER BLEND - BEHAVIOR THROUGH DOSE




Dose	18 mJ/cm ²	22 mJ/cm ²	26 mJ/cm ²
Resist (Only) + Tapered Etch	53.1	39.9	28.7
Resist + DSA Blend Shrink + Tapered Etch	36.0	26.2	19.9



~35% shrink from DSA & ~ 30% shrink from Etch is observed.
Min DSA CD ~ 20-25 nm, post-Etch min CD ~ 20 nm, no missing contacts.

E-TEST RESULTS BLEND – KELVIN


DSA IS YIELDING! STRONG TREND VS. CD OBSERVED



Excellent match of Resistance vs CD data of DSA-processed structures with litho-only reference. Current limit is $\pm 30\text{nm}$ CD (post-etch)

E-TEST RESULTS BLEND – 10K CHAIN





DSA IS YIELDING! NO STRONG DIFFERENCE BETWEEN DSA/NO-DSA



“It’s Alive!” – *Dr. Henry Frankenstein*

PS-PMMA BLOCK COPOLYMER SYSTEM

EV28-VA0 BCP DSA

MASK RESIST SUBSTRATE BCP (L_0 , nm) PMMA REMOVAL	EV28-VA0 GEN 3 GUIDE IMEC CVD + NL BCP-B (~44) WET ETCH	EV28-VA0 GEN 3 GUIDE IMEC CVD + NL BCP-C (~33) WET ETCH
Post-Litho		
	61P90-110	54P90-110
Post-Hard Bake, BCP Coat, BCP Anneal, & PMMA Removal		
	CD ~ 18 nm CD Shrink ~ 75%	CD ~ 15 nm CD Shrink ~ 73%

Our BCP Flow Is yielding options for EV28-VA0 CDs < 20 nm

Post-DSA LCDU looks very promising.

Pattern transfer studies are currently ongoing.

Open hole rate and placement accuracy are main figures of merit for further optimization.

CH SHRINK USING BCP

CLOSED CONTACT HOLES ?

w/o affinity control

with affinity control

FEM

110nm pitch

50-70nm litho CD

Final CDs $\pm 24\text{nm}$

Surface treatment for affinity control and wet development in TEL track shows a greatly improved 'open contact hole rate'.


OUTLINE

Introduction

Contact Hole Shrink (grapho-epitaxy)

Templated Process (grapho-epitaxy)

▶ Via/cut patterning at sub-EUV resolution






Honeycomb Process (chemo-epitaxy)

Summary

GRAPHO-EPITAXY FLOW


TEMPLATED DSA FOR HOLE MULTIPLICATION




P.-S. Wong et al. – Stanford/AMAT

Gridded Layouts –
193i + Pitch Division
+ DSA Cuts
with HVM DSA

193i + DSA PD




193i Templated DSA Cut





Y. Borodovsky - Intel

FLOW FOR TEMPLATED DSA




SOC: spin-on carbon
SOG: spin-on glass

FLOW FOR TEMPLATED DSA




After litho



After etch into SOG/SOC

TEMPLATED PROCESS

2-HOLE FEATURES



Very strong correlation between pre-pattern quality and position accuracy, open CH rate. The pre-pattern may require EUV resolution.

TEMPLATED PROCESS

IMPACT OF PRE-PATTERN QUALITY ON CONFINEMENT

After litho (ArFi NTD):




100 nm

After SoG/SoC etch:



After DSA fill:



Commensurability @ $L_0 = 37 \text{ nm}$

Very strong correlation between pre-pattern quality and position accuracy, open CH rate. The pre-pattern may require EUV resolution.

OUTLINE


Introduction

Contact Hole Shrink (grapho-epitaxy)

Templated DSA (grapho-epitaxy)

Honeycomb Process (chemo-epitaxy)


- ▶ Dense hexagonal array patterning



Summary

HONEYCOMB PROCESS





CHEMO-EPITAXY CH FLOW



This process can be used of contact hole healing, missing contact hole repair and contact hole multiplication.

CLOSED CONTACT HOLES IN EUV




Multilayer blank defects




30nm hp contacts printed with NXE:3100

Mask review with AFM

EUV variability due to stochastic effects



Photon distribution




Resist profile

30nm hp contacts at 20mJ/cm2


HONEYCOMB PROCESS

MISSING HOLE REPAIR VIA 1:1 PATTERNING

Pitch 58 nm



EUVL pre-pattern




Post DSA of BCP A

The ability of our flow to repair missing holes in an EUV pre-pattern is demonstrated, and could help solving the ML defect/variability issues.

LOCAL CD NON-UNIFORMITY


‘fast resist’

LCDU $1\sigma=1.9\text{nm}$
DtS= $25\text{mJ}/\text{cm}^2$




27nm

LCDU $1\sigma=1.4\text{nm}$
DtS= $22\text{mJ}/\text{cm}^2$



27nm


LCDU $1\sigma=1.7\text{nm}$
DtS= $22\text{mJ}/\text{cm}^2$



22nm


‘slow resist’

LCDU $1\sigma=1.3\text{nm}$
DtS= $68\text{mJ}/\text{cm}^2$




27nm

LCDU $1\sigma=0.9\text{nm}$
DtS= $56\text{mJ}/\text{cm}^2$



27nm

LCDU $1\sigma=1.0\text{nm}$
DtS= $53\text{mJ}/\text{cm}^2$



22nm

0.25NA



0.33NA




0.33NA



LCDU REPAIR VIA 1:1 PATTERNING

ENABLING LOW DOSE EUV RESISTS




EUVL pre-pattern
 1σ LCDU = 2.3 – 2.4nm

Post DSA of BCP
 1σ LCDU = 1.4 – 1.5nm

LCDU of DSA patterns largely depends on the BCP quality. We expect the post-DSA LCDU to improve as we transition to BCPs with sub-50nm pitch (NXE:3300). DSA may enable working with a higher LCDU EUV pre-pattern (ie fast resist!).


LCDU REPAIR CONTD.

UP TO 50% LCDU IMPROVEMENT




58nm pitch CH

FREQ. MULTIPLICATION SCHEMES



3x frequency multiplication

$$L_0 = p/\sqrt{3}$$





4x frequency multiplication



$$L_0 = p/2$$

For $L_0 = 30\text{nm}$ we need 52nm pitch pre-pattern for 3x and 60nm pitch for 4x frequency multiplication

3X FREQUENCY MULTIPLICATION



200k mag



100k mag

Post litho

Pitch 52 nm
17 mJ/cm²



24 nm Average CD
> 4 nm 1 σ LCDU

Post DSA



Pitch 30 nm

13 nm Average CD
< 0.5 nm 1 σ LCDU

4X FREQUENCY MULTIPLICATION



200k mag



100k mag

Post Litho

Pitch 60 nm
16 mJ/cm²

27 nm Average CD
> 3 nm 1 σ LCDU

Post DSA

Pitch 30 nm

13 nm Average CD
< 0.5 nm 1 σ LCDU

OUTLINE

Introduction

Contact Hole Shrink (grapho-epitaxy)

Templated DSA (grapho-epitaxy)

Honeycomb Process (chemo-epitaxy)

Summary

SUMMARY

Very good progress in materials/process

- ▶ DSA truly made it from the lab to the fab
- ▶ Focus now is on increasing process window by neutral layer material and etch process optimization

DSA as a **competitor**

- ▶ DSA can achieve EUV resolution starting from ArF(i) guide patterns

DSA as a **complementary technique**

- ▶ Pre-pattern quality of EUV lithography seems mandatory to guarantee pattern placement in the templated process (better confinement)
- ▶ DSA can clearly play a role in rectifying/healing the EUV resist image

DSA as an **enabler** for EUV lithography

- ▶ Low LCDU can be achieved using a fast resist and DSA, which could be key enabler for EUV

ACKNOWLEDGEMENTS

Material Suppliers

- ▶ AZ-EM
- ▶ JSR
- ▶ TOK

TEL etch and Clean Track

- ▶ Doni Parnell, Ainhoa Romo Negreira, Mark Somervell, Kathleen Nafus