

Development of EUVL Collector Technologies for Infrared Radiation Suppression

Rigaku Innovative Technologies: Michael Kriese, Yuriy Platonov, Licao Jiang, Jim Rodriguez

L-3 Communications – Integrated Optical Systems: Ulrich Mueller, Jay Daniel, Shayna Khatri, Adam Magruder

National Institute of Standards and Technology: Steven Grantham, Charles Tarrio, Thomas Lucatorto




INTEGRATED OPTICAL SYSTEMS



- **BACKGROUND**
- **MACHINING & FIGURING**
- **INFRARED REJECTION**
- **SMOOTHING LAYER**
- **NIST UPGRADE**
- **MULTILAYER RESULTS**

Background

- LPP sources generate 10.6 μm IR radiation
- Mo/Si ML optics reflect IR radiation through IF




Methods to Reduce IR

Filter (IPM-RAS)

~ 30% EUV loss

~ 125X IR suppression





Chkhalo et. al., Proc SPIE 8076 (2011)

AR Layers (FOM)

~ 25% EUV loss

~ 250X IR suppression



Medvedev et. al., Opt. Lett. 37, pg. 1169 (2012)



Methods to Reduce IR

Diffraction Grating (FOM)

- ~ 8% EUV reduction
- ~ 70X IR suppression

*Medvedev et. al., Opt. Lett., 36,
Issue 17, p. 3344 (2011) &
2012 International Symposium
on Extreme Ultraviolet Lithography,
Brussels, Belgium*


**“Test Structure” Results
Rp 61%**



Achievement of the IRRC

(Infra-Red Rejection Collector)


- Ellipsoidal collector with $NA \gtrsim 0.22$ surface with multilayer to focus 13.5nm



Achievement of the IRRC


(Infra-Red Rejection Collector)

- Ellipsoidal collector with $NA \gtrsim 0.22$ surface with multilayer to focus 13.5nm
- Tuned grating directly on optical surface to diffract $10.6\mu\text{m}$ (IR) away from IF aperture



MACHINING & FIGURING

Process Flow



Demonstration Collector: ~410mm dia ($\text{NA} \gtrsim 0.22$)




Grating structure

INFRARED REJECTION (IRR)



The theoretical performance of different grating types for IR rejection:

Physical mode	Zero order	Fundamental positive order +1	Fundamental negative order -1	+2 order	-2 order	+3 order	-3 order
Binary amplitude	25%	10.1%	10.1%	0%	0%	1.1%	1.1%
Sinusoidal amplitude	35%	6%	6%	0%	0%	5%	5%
2 phase levels	0%	40.5%	40.5%	0%	0%	4.5%	4.5%
4 phase levels	0%	81%	0%	0%	0%	0%	10%
8 phase levels	0%	94.9%	0%	0%	0%	0%	0%
16 phase levels	0%	98.7%	0%	0%	0%	0%	0%
Blazed phase	0%	100%	0%	0%	0%	0%	0%
Sinusoidal phase	12%	34%	34%	0%	0%	0%	0%


The grating period is optimized to provide sufficient separation of the 0th order and the +/-1st order.





- Grooves contoured to the elliptical surface & are central-symmetric rings
- Groove pitch & depth vary with distance from collector center to account for changing angle of incidence




Integrated Optical Systems: IR Rejection Test Stand




- IR rejection test uses an incoming collimated beam reflecting from a ½-in tooling ball to simulate a point source
- This method generates some spherical aberration which contributes blur to the zero order diffraction
- The nominal spot size of the blurred-zero order is contained within 1mm OD, well within the exit aperture
- Detector precision aligned to plane of IF
- IR rejection precision $\pm 0.1\%$



125X IR Suppression on Demo collector



Fraction of light in IF aperture is $0.8\% \pm 0.1\%$ of total IR radiation



SMOOTHING LAYER

Glassy smoothing layer evaluated with AFM

0.14 – 0.29nm rms over 2.2 μ m

file : O:\TestData\4653\AFM\Demo\082213\0822B1.GNT


units: x = nm
y = nm
z = nm
xspac: 8.627e-006
yspac: 8.627e-006
ngx : 256
ngy : 256
gxcen: 0.0011
gycen: 0.0011

x-apr: 0.00
y-apr: 0.0022

z min:-0.8735
@ (256, 256)
z max: 1.606
@ (256, 256)
z avg: 0.01566

ndata: 65535

ix : 129
iy : 129
xpos : 0.0011
ypos : 0.0011
r : 0.0016
theta: 45.0000
zval : -0.141



z ptv: 2.48nm

z rms: 0.214nm



Traditional Comments: 'this file = cropgint -10822b1.mmm

0.29 – 0.39nm rms over 8.7 μ m

file : O:\TestData\4653\AFM\Demo\082213\0822A7.GNT


units: x = nm
y = nm
z = nm
xspac: 3.412e-005
yspac: 3.412e-005
ngx : 256
ngy : 256
gxcen: 0.00435
gycen: 0.00435

x-apr: 0.01
y-apr: 0.0087

z min:-1.747
@ (256, 256)
z max: 3.155
@ (256, 256)
z avg: 0.02558

ndata: 65536

ix : 129
iy : 129
xpos : 0.0044
ypos : 0.0044
r : 0.0062
theta: 45.0000
zval : -0.0282




z ptv: 4.903nm

z rms: 0.3139nm



Traditional Comments: 'this file = cropgint -10822a7.TM2




NIST REFLECTOMETER UPGRADE FOR LARGE OPTICS



Upgrade

Sample chamber motion axes





Sample Chamber

- **Samples up to 45 cm diameter, 40 kg mass.**
- Six axes sample motion, three axes detector motion.
- UV spot size: 1mm x 1mm (FWHM)
- Can be fitted with external end-stations for assembled instrument calibration.

Monochromator

- **VLS grating:**
 - 600 mm⁻¹, 7 nm - 35 nm
- **Wavelength Uncertainty: 0.01 nm**
- **High throughput ($P_{\text{EUV}} > 1 \mu\text{W}$)**
- **Fixed exit slit**
- **Reflectivity uncertainty:**
Rp ~0.25% near 13.5 nm

NIST upgraded to handle 45cm collectors




Goniometer can't be tilted far enough to make all measurements in vertical plane. Two angles should be set to add up to the incidence angle. It allows making measurements that simulate un-polarized light by setting reflection plane to 45° from vertical, thus converting this into un-polarized light (as from a plasma source) measurement.

A Zemax model was developed to predict the performance of the optic at various angles and positions. This model was used to place the optic and detector and to confirm alignment of the optic.

MULTILAYER RESULTS


Performance at Normal AOI

5°




Performance at Design AOI

$\sim 5^\circ$ to $\sim 35^\circ$



Performance at Design AOI

$\sim 5^\circ$ to $\sim 35^\circ$




SUMMARY

Current Results:


- Demo collector: 410mm, $NA \gtrsim 0.22$
- IR Suppression (grating) 125X
- Area-weighted EUV Rp 50.9%

Future Efforts:

- HVM-ready facility for 750mm optics (Jan-2014)
- Refurbishment Paths



Thank You



**HVM (9-target) Inline Deposition System for 750mm Optics
— to be installed late 2013 —**