The AIS wavefront sensor

An in-situ optical test via localized wavefront curvature sensing

Ryan Miyakawa¹, Xibin Zhou², Antoine Wojdyla¹, Yudhi Kandel⁴, Michael Goldstein^{2,3}, Dominic Ashworth², Kevin Cummings², Yashesh Shroff³, Greg Denbeaux⁴, Patrick Naulleau¹

- ¹ Center for X-ray Optics, LBNL
- ² Sematech
- ³ Intel
- ⁴ CNSE, University at Albany











Motivation




1. High NA

2. Space

3. Cost

4. Convenience



Outline



1. Review of working principle


2. Experimental realization and design considerations

3. Recent results from optical prototype

Basic idea: Aberrated optical systems have nonuniform focus signatures over pupil




No aberrations



Basic idea: Aberrated optical systems have nonuniform focus signatures over pupil





Aberrated




Zernike polynomials have curvature signature











Zernike polynomials have curvature signature






Z6: Coma




Curvature signature




Generate a curvature library

Ν	Aberration	Probe	Δf
3	Focus		[+,-,+, -, -, +]
4	Stig		[-,-,+, -, -, +]
5	Stig		[-,-,+, +, -, +]
6	Coma		[+,-,+, -, +, +]
7	Coma		[+,+,+,-,+]
8	Spherical ([-,+,+, +, -, +]
9	Trifoil		[+,-,-, -, +]
10	Trifoil		[+,-,-,+,+]

Curvature library




Wavefront



Focus shifts




Curvature library



Focus shifts




Wavefront




Wavefront sensor outline



Step 1: Probe localized regions of the pupil



Step 2: Find the plane of best focus for each probe




Step 3: Convert these focus shifts into an aberration map using **curvature library**

$$\Delta f \longrightarrow \frac{1}{2} \frac{1}{2$$

Experimental realization and design






Grating orientation design considerations



Curvature probe orientation determined by grating orientation



Require enough orientations to make reconstruction well-conditioned




^{* 45-}astigmatism has no curvature in x-y directions

Illumination control




SEMATECH Berkeley MET



Condenser


Programmable illumination via pupil scanners


Albany MET



Pupil wheel with configurable illumination masks

Number of probe positions depends on size of Zernike reconstruction basis





Minimum # of probe positions:

8 Zernikes: 6 probes


15 Zernikes: **16 probes**


Illumination control



* Number of probes is more important that their specific location


Albany MET3 pupil wheel






Focus sensor






Focus sensor








Best focus given by the z value that maximized the contrast of the diode signal modulation

Optimizing design for smallest errors







Hexagonal pinhole array is *simultaneously* compatible with all 3 grating orientations

Mask design






Reticle-plane mask





Wafer-plane stencil mask



AIS detector noise test









Optical prototype layout






Zone plates allow programmable aberrations






Zone plates allow programmable aberrations





Zone plate mask layout





REF		Z4 10 mWaves	Z4 20 mWaves	Z4 100 mWaves	
Z5 20 mW:		Z5 50 mWaves		Z7 50 mWaves	Z7 100 mWaves
REF		Z6 10 mWaves	Z6 20 mWaves	Z6 100 mWaves	
	aves	Z9 50 mWaves		Z10 50 mWaves	
REF		Z8 10 mWaves	Z8 20 mWaves	 Z8 100 mWaves	
		ZII 50 mWaves	Z12 20 mWaves	Z13 20 mWaves	
Z14 20 mWaves		Z14 50 mWaves	Z15 20 mWaves		ZI-15 50 mWaves
REF			ZI-8 20 mWaves	ZI-8 100 mWaves	ZI-8 200 mWaves

Zone plate mask

- 144 Zone plates
- Programmed with Zernikes Z₄ through Z₁₅ of varying amplitudes
- 3 different numerical aperture settings

Optical prototype parameters



NA: **0.2**

lambda: 543 nm


Aberrations tested: Astigmatism, Coma,

Spherical, Z₁₋₈, Trifoil

Probe sites: **8**, (12)

Grating orientations: 3 + 1


Focus steps: 21



Astigmatism (Z₅)




Input wave



RMS error: \\142

AIS reconstructed wave






Difference



Coma (Z₇)




Input wave




RMS error: λ/160

AIS reconstructed wave






Difference




Spherical (Z₈)




Input wave







RMS error: λ/100

AIS reconstructed wave






Difference




Linear combination (Z₄ - Z₈) CXR











RMS error: \\\\30

AIS reconstructed wave









Difference

Trifoil (Z₁₀)



Input wave






RMS error: $\lambda/68$

AIS reconstructed wave






Difference



Precision





* High stability of BF measurements.

Accuracy of optical prototype likely limited by quality of optical elements

Probe location


Precision better than $\lambda/150$

212.2

AIS wavefront sensor summary



- Optical demonstration of $\lambda/30$ wavefront accuracy with better than $\lambda/150$ precision
- Successful reconstruction of all primary Zernike polynomials as well as Trifoil



- Diode package is built and has demonstrated good noise properties.
- First EUV test planned for January in current Albany MET

Acknowledgements

Rick Chao Seno Rekawa Doug Van Camp Farhad Salmassi Mike Dickenson Rene Delano Carl Cork Will Cork lacopo Mochi **Jeff Gamsby** Paul Denham











Contact
Ryan Miyakawa
rhmiyakawa@lbl.gov