

# 2013 International Symposium on Extreme Ultraviolet Lithography

Toyama, Japan ● 6 - 10 October, 2013



## **EUV mask imaging system based on the scanning reflective microscopy**

Seong-Sue Kim, Donggun Lee, Jongju Park, Eokbong Kim,  
Chan-Uk Jeon, Hanku Cho, Byeonghwan Jeon, Changhoon Choi (Samsung),  
Chris Anderson, Ryan Myakawa, and Patrick Naulleau (LBNL)

**October 9, 2013**




# Introduction

- In fabricating EUV mask, the printability review of the phase defects is a necessary step and it's possible only by an actinic imaging tool.
- Previously a timing gap was expected between the HVM scanner and the commercialized mask imaging tool.
- A bridge tool was developed to fill the gap based on the scanning reflective microscopy using the high-harmonic EUV source and the zone plate optics.

# Why zone plate?

- The full field imaging system with a plasma source and mirror optics is too expensive and needs a long lead time for a bridge tool purpose.
- ➔ The zone plate optics was considered to be an alternative option.



# Why high harmonic EUV source?

- In order to use a zone plate for full field imaging an EUV source with extremely narrow spectral bandwidth is needed.
- The synchrotron beam filtered by a monochrometer satisfies the spectral bandwidth spec., but for the manufacturing purposes a stand-alone source is required.
- ➔ Among the available stand-alone EUV sources high harmonic has the most narrow spectral bandwidth.

# Why scanning?



- The high harmonic EUV source is both monochromatic and stand-alone, but the spectral bandwidth is too large to be used for a full field imaging and the power is too small to be filtered by a monochromator.
- ➔ But in the scanning-type imaging system using on-axis focused beam, the off-axis aberration can be mitigated and consequently the spectral bandwidth requirement can be reduced significantly.



## Scanning EUV reflective microscopy

# Scanning EUV reflective microscopy(SERM)


## Scanning EUV Reflection Microscopy(SERM)




Focused beam spot  
(PSF of scanner)




Scanning(convolution)



Mask pattern with  
a phase defect



by SERM





by Scanner

"US8335038, by Dong-Gun Lee et al"

# Outline of the tool development


- The zone plate optics was designed and fabricated by LBNL.
- The high harmonic source was developed by Samsung and FST using COHERENT Ti:Sapphire femtosecond laser( $\lambda = 800\text{nm}$ , pulse width= 46fs) and the whole system was integrated by Samsung.








# Configuration of the high harmonic source

Ti:Sapphire femtosecond drive laser( $\lambda=800\text{nm}$ , 46fs)




High Harmonic Generation






# High harmonic EUV photon generation




- By the highly intense ( $10^{14} \sim 10^{15} \text{ W/cm}^2$ ) IR femtosecond laser electrons are ionized, accelerated coherently, and recombined to generate the EUV light (59-th harmonic).

# Characteristics of the high harmonic source


EUV Power = 23.7nW




Divergence = 0.195mrad



Bandwidth( $\Delta\lambda/\lambda$ ) = 1/280




Wavefront error =  $\lambda/67$




# Zone plate optics

- A free-standing elliptical zone plate with  $NA = 0.35(4X)$  and  $f = 533\mu m$  was fabricated.
- All diffraction order radiations other than the 1<sup>st</sup> order are blocked by the order sorting aperture(OSA) to enhance the contrast.


Zone plate optics with an OSA



Elliptical zone plate with 6° CRA




Optics package




# Characteristics of the zone plate

- The wavefront error of the zone plate:  $\lambda/20$   
(illuminated by the high harmonic source and measured by the 2D grating shear Interferometer)
- Focused beam spot reconstructed from the wavefront: **84nm**(FWHM)  
→ diffraction limited


2D grating shear Interferogram



Wavefront error




Focused beam spot




# Scanning stage system

- Hybrid scanning stage is applied to construct an aerial image from the focused beam spot.
- The position of the stage at each image acquisition point is measured by an interferometer and used in the image reconstruction.






# EUV mask imaging system






# Results: Pattern image

25nm HP(1X) L/S pattern








30nm HP(1X) C/H pattern








- ✓ The major sources of the LWR are the low source power (shot noise), the mask LWR, and presumably mask surface roughness.

# Results: Phase defect images

- Phase defect imaging sensitivity(programmed pit defect)


Defect size (SEVD)	58nm	47nm	37nm	26nm	21nm
Defect image					

- Focus behavior of the phase defect(28nm-SEVD native bump defect)


Defocus	-1.3 $\mu$ m	-0.7 $\mu$ m	0 $\mu$ m	0.7 $\mu$ m	1.3 $\mu$ m
Defect image					

# Results: Phase defect in a patterned mask


Mask SEM Image



Wafer SEM Image



Mask actinic Image



- ✓ Phase defect printability on a wafer is reproduced successfully in the actinic image by this tool.

# Application

- **This tool can be used for**
  - ✓ Review of phase defect printability for both patterned mask and ML blank
  - ✓ CD verification after repair of both pattern and phase defects
  - ✓ Studies on the surface roughness effect etc...
- **Once commercial EUV mask imaging tool is installed for HVM, this tool can be upgraded to be a high-NA system, which is possible by simply changing the zone plate and the bending mirror.**

# Summary

- Using the concept of the scanning EUV reflective microscopy an EUV mask aerial imaging system was developed.
- An aberration-free( $< \lambda/67$ ) high harmonic EUV source was developed using a femtosecond IR laser and a gas cell.
- A free-standing elliptic zone plate optics was developed and a diffraction-free beam spot was obtained.
- Reviewing capability of the phase defects less than SEVD-21nm were confirmed and the defect printability on the wafer pattern is reproduced successfully.
- This tool will be used for reviewing phase defect printability and upgraded for high-NA EUV studies.

# Acknowledgement

**I'd like to thank Prof. David Attwood who encouraged me to apply the high harmonic EUV source in developing EUV mask imaging system.**