




Abstract


Since the photon energy of EUV light exceeds the band gap of all materials used in refractive optics, it is necessary to use reflective optics when performing EUV lithography. These mirrors consist of Si/Mo stacks and have a protective capping layer. Upon exposure to air, oxidation of the capping layer and diffusion of oxygen through the capping layer to the outermost Si layer may occur. In addition, Si may diffuse through the capping layer to the surface, resulting in a surface SiO_x layer. The presence of oxygen will result in absorption of EUV radiation and distortion of the image. In this study, angle-resolved XPS measurements were performed on mirrors with capping layers of either Ru or B₄C. This technique allows extreme surface sensitive analysis of the elemental composition of the mirror. Our results indicate that for Ru capping layers that have a thickness of 2.5 nm, Si diffusion to the surface occurs at room temperature. Annealing the mirror was found to enhance the diffusion rate. For mirrors with a B₄C capping layer, very little Si diffusion was observed at room temperature. After annealing the B₄C mirrors to 250°C, only a slight amount of Si diffusion was observed.

Angle Resolved B₄C Si Spectra




B₄C is a robust capping layer. Neither heat nor time result in significant Si diffusion

2.5nm Ru Capping Layer UV/DIW Cleaning Experiment



Cleaned 5x



5X Cleaned
then Annealed



Cleaned 50X



Cleaned 50X
then Annealed

Ru Si Spectra





- Si does not diffuse to the surface with a 5nm Ru capping layer except after anneal
- SiO_x dominates in air anneal
- There might be some silicide formation at the interface upon annealing
 - Peaks are slightly asymmetric
 - Slight shift of peak

B₄C and B₄C /Ru Si Spectra





- B₄C remains robust against Si diffusion and oxidation under many different conditions
- The 1 nm of B₄C on top of 2.5nm Ru offers some protection, though it may be due to the total thickness of the capping layer

Ru Si Spectra




- Air anneal leads to greater oxidation
- A thin water/hydroxide layer is present on top of the capping layer
 - Surface sensitive scan shows a drop in RuO_x peak intensity
 - SiO_x is present in the 5nm Ru samples (see Si-2p slide) SiO_x peak becomes more prominent after H₂ dosing the air annealed sample
 - SiO_x peak becomes more prominent after Vac annealing the 5nm sample

B₄C and B₄C /Ru O Spectra



- B₄C is not easily oxidized
- The 1 nm of B₄C on top of 2.5nm Ru offers some protection to the Ru layer, though it may be due to the total thickness of the capping layer



Understanding XPS



High energy monochromatic photons strike the sample and eject electrons. The binding energy of the electrons is equal to the energy of the incident photon energy minus the kinetic energy of the photoelectron and the work function of the sample. The spectra of binding energies are then compared to literature values for elemental and chemical state analysis. By changing the detection angle, it is possible to change the surface sensitivity. The angle is measured off of the surface normal (the greater the angle, the more surface sensitive the measurement is).

Conclusion

- Si diffuses through 2.5 nm thick ruthenium capping layers at room temperature
- Thicker Ru can be used, but this reduces reflectivity
- No Si diffusion is found for 2.5 nm B₄C capping layers



lattice spacing close to that of half the wavelength of 13.5 nm light. Additionally, the components of the two layers must not significantly diffuse into one another. For our experiment, forty alternating layers of silicon and molybdenum of about 3.5 nm thickness were used. In addition, a 2.5 nm capping layer of ruthenium was deposited to prevent the oxidation of the top layer of silicon, and to act as an etch stop for the development of a reflective mask.

