



ASML

Laser Produced Plasma Source for NXE:3300B

EUVL Symposium
Washington DC

Oct 27th, 2014

David C. Brandt

Outline

1. NXE:3300 source overview at customer Fabs
2. LPP Development in the Lab
3. EUV power scaling to 250W
4. Summary



EUV status:

Demonstrated >500 wafers per day at customer sites



- More than 500 wafers per day demonstrated during endurance tests at 2 customer sites
- 7 NXE:3300B systems qualified and shipped to customers
- 4 more NXE:3300B systems being integrated, one more shipment planned for Q4
- 4th generation NXE system (NXE:3350B) integration ongoing
- EUV cleanroom extension is under construction


NXE:3300B - Good Imaging Performance

EUV (single expose)


ASML

EUVL
Symposium


Slide 4



Tip-to-tip




Tip-to-line




Lines and spaces

Conv. 31 nm




27 nm Quasar




Tip-to-tip

Conv. 20 nm



19 nm Quasar




Tip-to-line

NXE:3300B LPP Source Status in the Fab

40W Operating Node

ASML


Public
Slide 5
9 July 2014



Industrialization of NXE:3300B

NXE:33x0 Source Development Underway

Development and Engineering



NXE:33x0
Source
(Cymer 4)



250W
Drive Laser
(Cymer 4)

Manufacturing



NXE:3300B
Vessel
Production





NXE:3300B
Training

Produced Wafers on NXE:3300B at Customer Sites


Reaching output in 8 months that took NXE:3100 2 years

Output approaching 20,000 wafers



NXE:3300B Source Operating for Months at >40W

Stable LPP sources at customers



Four Customer Sources

Weekly average power measured in the source
Normalized to clean collector conditions

NXE:3300B Collector Protection on Field Sources


~0.5% EUVR loss per Gigapulse

ASML

EUVL
Symposium

Slide 9

Collector Transmission



Current ave. utilization ~2.5Gp per week

Outline

1. NXE:3300B source overview at customer Fabs
2. LPP Development in the Lab
3. EUV power scaling to 250W
4. Summary




NXE:3300B LPP Source Status in the Lab


Development of LPP Technology for Production

ASML


Public
Slide 11
9 July 2014



Def: Dose Margin: lost potential used to stabilize the output power



Ref. SPIE 2014




- Much of the lost potential can be recovered with advanced control

- Physical forces distort droplet trajectories causing energy instability


Local Force Compensation (LFC) Controls

Stabilizes dose by compensating for forces on droplets


Droplet Position Stability with/without plasma





Y-position



Z-position



Forces on Droplets



Droplet Generator

NXE:3300B 80W Source Power Demonstrations

Multiple Runs on Lab Sources



ASML

EUVL
Symposium

Slide 14



In the Lab (@ASML)

Dose Error



<0.5%
Meets requirement
of <1.0% 3 σ

EUV Power



~80W

Data collected on
Cymer 1, stand alone
test source,
NXE:3300B



Repeatable 80W one hour test runs

CYMER
An **ASML** company

>3% Conversion Efficiency (CE) at 80W

ASML

EUVL
Symposium
Slide 15






Multiple runs at 80W with >3% CE on NXE:3300B

Continuous Stable Source Operation at 80W

Excellent die yield, low dose margin

ASML

EUVL
Symposium
Slide 16



**Continuous operation at 80Watts of EUV
(good collector protection)**




CYMER
An ASML company

NXE:3300B Collector Protection


*Configuration optimized to increase source availability
and achieve >100Gp collector lifetime*

ASML


Public
Slide 17




Initial image




1.58 Gp




2.41 Gp



4.78 Gp



6.36 Gp




**Improved Source Availability
by eliminating a long
maintenance procedure**

Data collected on M1, stand alone test source, NXE:3300B


CYMER
An **ASML** company

In-situ Collector Cleaning Demonstration

Significant improvement to COO and Availability



As New



After Cleaning

- 'As New' Reflectivity restored with in-situ cleaning

**In-situ collector cleaning capability demonstrated with
NXE:3300B compatible configuration**

Outline

1. NXE:3300 source overview at customer Fabs
2. LPP Development in the Lab
3. EUV power scaling to 250W
4. Summary



NXE:3300B Source power scaling to 250W

Key scaling parameters: laser power, CE, dose margin

ASML



Confidential

Slide 20

June 25, 2014

Scaling parameter			
EUV Power in Burst (W)	40	80	250
Laser Power* (kW)	13	16	27
Conversion Efficiency (%)	2.5	3.5	4.5
Dose margin (%)	35	20	10

* MP on droplet



CYMER
An ASML company



High Power Drive Laser (Power Amplifiers)

Supports roadmap requirements to get to 250W


ASML

EUVL
Symposium

Slide 21





- Stable power through duty cycle
- CO₂ power needed for 125 wph productivity



- Operation at 50kHz
- Good beam quality

High Power Seed System (Master Oscillator)



High Power Drive Laser for 250W EUV



- Master Oscillator output power increased from
 - Better matched with the new high power drive laser
- Enables >40kW laser power

Stabilized High Output Power

Prototype High Power Seed System (HPSS)



- Highest per-pulse EUV energy successfully operated with dose control


Increased Conversion Efficiency

Enabled by optimized target shape and size

ASML

EUVL
Symposium

Slide 24



Data collected on Pilot 7
(MOPA Prepulse), stand
alone test source, 3100 drive
laser with proto HPSS



Prepulse changes the tin droplet into an optimized target shape
leading to High CE

CYMER
An **ASML** company

Advanced Controller Improves Dose Margin to $<10\%$



Also increases power by 10%

Advanced controller: 75W open loop power \rightarrow 70W closed loop power



Advanced controller :
Higher open loop power due
to improved CE
Good dose control at $<10\%$
dose margin

Current controller: 67W open loop power \rightarrow 40W closed loop power



Data collected on Pilot 7
(MOPA Prepulse), stand
alone test source, 3100
drive laser with proto HPSS

Current controller:
Good dose control at 40%
dose margin

Outline

1. NXE:3300 source overview at customer Fabs
2. LPP Development in the Lab
3. EUV power scaling to 250W
4. Summary



Summary

- **Industrialization of NXE:3300B; sources installed and operating at customers**
 - Stable source operation allowing integration at chipmaker fabs
 - 500 wpd productivity in 2014
 - Collector lifetime >50 Gpulses
- **MOPA-Prepulse source technology demonstrated improvements**
 - 80W expose power, long runs, multiple sources
 - Collector lifetime demonstration extrapolates to >100Gp
- **In-situ collector cleaning technology demonstrated**
 - Improves both COO and Availability
- **Technology feasibility for 125 wph productivity demonstrated**
 - >35kW Drive Laser power demonstrated (27kW needed)
 - ~4% EUV conversion efficiency demonstrated
 - <10% dose margin demonstrated with advanced controls

Acknowledgements

Thank you!

San Diego and Veldhoven
EUV Source Team

ASML
EUVL
Symposium
Slide 28



ILLINOIS
UNIVERSITY OF ILLINOIS AT URBANA-CHAMPAIGN

optiXfab.



**Colorado
State**
University



TNO innovation
for life

CYMER
An **ASML** company

The image features the ASML logo in a bold, dark blue, sans-serif font. The logo is positioned on the left side of the frame. The background is a light blue gradient with abstract, flowing white lines that sweep across the lower half of the image, creating a sense of motion and modernity.

ASML