



# VARIABILITY OF EUV RESIST OUTGAS TEST RESULTS : COMPARISON OF OUTGAS VERSUS CONTAMINATION BEHAVIOR AT MULTIPLE TEST SITES USING MODEL EUV RESISTS

**I. POLLENTIER, Y.C. LIN, A. TIRUMALA VENKATA, G. VANDENBERGHE, IMEC**

**R. F. BERG, S. HILL, C. S. TARRIO, T. B. LUCATORTO, NIST**

**E. SHIOBARA, Y. KIKUCHI, T. SASAMI, S. INOUE, EIDEC**



# OUTLINE

Introduction : round robin variability

RGA outgas metric for contamination

Within-site relationship of outgas/contamination

Site-to-site relationship of outgas/contamination


How to use outgas contamination relationship towards  
'round robin' variability ?

Summary

# OUTGAS TESTING


Resist outgassing is potential risk for NXE:3x00 and needs to be tested according to a procedure

## Example of Contamination Growth (CG) tester (imec)



Different outgas test qualification sites have different test infrastructure, resulting in variability ('round robin' testing) despite the well-defined procedure.

[N. Harned, IEUVI ResistTWG, Feb'2014]



**'cleanable contamination'**

CC  $\leq$  3nm  $\rightarrow$  10nm (NXE3100)


CC  $\leq$  3nm  $\rightarrow$  10nm (NXE3300)

**'non-cleanable contamination'**

NCC  $\leq$  0.23% (NXE3100)

NCC  $\leq$  0.16% (NXE3300)

['Round Robin 2' reported at IEUVI Resist TWG meeting, Feb' 2014]




# ROUND ROBIN VARIABILITY

In order to reduce the gap of inter-site CG variability, collaborative work is done in between EIDEC, NIST, Sematech, and imec under advice of ASML (reported in detail on recent IEUVI resist TWG meeting), and 3 main root causes of variability have been identified.

## Temperature


Stability in time is key, and site-to-site matching needs to be checked.



T. Lucatorto (NIST), IEUVI ResistTWG, Feb' 2014]

## Contamination limited regime (CLR)

CG spot on witness sample



Intensity of WS exposure needs to be sufficiently high. Non-CLR can underestimate the contamination.

## A/PS ratio

(A :wafer area;  
PS : pumping speed)

Different outgas test sites expose different wafer areas, and the pumping speed of testers are different. ASML proposed to use common A/PS ratio


# ROUND ROBIN VARIABILITY

## Strategy for Reducing CG Gaps among Test Sites

Presented by S. Inoue (EIDEC), IEUVI Resist TWG meeting, Washington, Oct'2014


### Step 1:

Set compromised wafer temperature for all test sites




### Step 2:

Establish contamination-limited regime for 10nm criteria



### Step 3:

Set common ratio between exposed Area and Pumping Speed (A/PS)



Step 4: Confirmation of tester reproducibility

Step 5: Re-calibration at all test sites



IEUVI Resist TWG, Washington D.C., Oct. 26, 2014



2

The goal of this presentation is to validate and show progress, but also to include RGA as complementary information

# OUTLINE

Introduction : round robin variability

RGA outgas metric for contamination

Within-site relationship of outgas/contamination

Site-to-site relationship of outgas/contamination


How to use outgas contamination relationship towards  
'round robin' variability ?

Summary

# PRIOR WORK ON RGA CG CORRELATION TO CG

I. Pollentier et al, SPIE 2013

## RGA FOR CONTAMINATION QUALIFICATION




imec


© IMEC 2013

Ivan Pollentier SPIE 8679-19, San Jose (2013)

**Integrated COR can be considered as independent & complementary measurement to the CG**



**integrated COR (contaminating outgassing rate)**



imec

© IMEC 2014

I. POLLENTIER - EUVL SYMPOSIUM, WASHINGTON, 28 OCT 2014

7

# OUTLINE

Introduction : round robin variability

RGA outgas metric for contamination

Within-site relationship of outgas/contamination

Site-to-site relationship of outgas/contamination


How to use outgas contamination relationship towards  
'round robin' variability ?

Summary






# WITHIN-SITE OUTGAS/CONTAMINATION

## CG testing at imec




## Model resists provided by EIDEC

EIDEC distributed 5 model resists amongst the qualification sites for next step round robin; Two resists are expected to be high contaminating (CG = 7-10nm)



## Contamination limited regime (CLR)

CG spot on witness sample




Intensity of WS exposure needs to be sufficiently high. Non-CLR can underestimate the contamination.

## A/PS ratio (A :wafer area PS : pumping speed)

Different outgas test sites expose different wafer areas, and the pumping speed of testers are different. ASML proposed to use common A/PS ratio





# WITHIN-SITE OUTGAS/CONTAMINATION

## CG testing at imec




## Model resists provided by EIDEC

EIDEC distributed 5 model resists amongst the qualification sites for next step round robin; Two resists are expected to be high contaminating (CG = 7-10nm)




**Good correlation between EUV exposed and Egun exposed CG results.**



**Good correlation between outgassing and contamination.**



# WITHIN-SITE OUTGAS/CONTAMINATION

## CG testing at imec




*non-CLR ?*

*WS testing shows that std imec condition is in CLR !*





*Good correlation between EUV exposed and Egun exposed CG results.*



*RGA confirms that max CG of std condition meets CLR and even can predict CRL violations !*

# RR TESTING AT IMEC : A/PS

## Area / Pumping Speed



*Differences in CG vs. PS slope could be responsible for different CG behavior.  
Agreement with integrated COR.*

**Sources of variability (CLR and PS/A) are confirmed to be important !**

**The integrated COR (RGA) can help in the investigation !**

# OUTLINE

Introduction : round robin variability

RGA outgas metric for contamination




Within-site relationship of outgas/contamination

Site-to-site relationship of outgas/contamination


How to use outgas contamination relationship towards  
'round robin' variability ?

Summary

# RGACG CORRELATION SITE-TO-SITE



*One material evaluated by RGA at 3 different sites.  
Similar peak masses are found, however with different relative magnitude.*




RGA peak differences can be due to many reasons :

- RGA hardware and measurement setting
- Distance and/or line-of-sight between RGA and wfr


# RGA CG CORRELATION AT DIFFERENT SITES ?

imec





**Good correlation both for commercial resists and model resist in EUV and Egun**

EIDEC





# RGA CG CORRELATION AT DIFFERENT SITES ?

imec



EIDEC



*Power weight needs to be tuned to compensate the lower detection of peaks at higher amu's*



# OUTLINE

Introduction : round robin variability

RGA outgas metric for contamination

Within-site relationship of outgas/contamination


Site-to-site relationship of outgas/contamination

How to use outgas contamination relationship towards  
'round robin' variability ?

Summary


# USE OF RGA-CG CORRELATION TO (RR) CG VARIABILITY INVESTIGATION

Is round-robin variability related to variability in outgassing or contamination ???




Root cause is (very likely) contamination ! (e.g. CLR)

Away from correlation : 'mismatch' between outgassing and CG



['Round Robin 2' reported at IEUVI Resist TWG meeting, Feb' 2014]

Site-to-site variability




if RGA/CG correlation is observed at both sites :

Root cause is outgassing !

[can still have many sources : dose, PS/A, ...]


On correlation : outgassing and CG are 'matching'



● Example of resist

# USE OF RGA-CG CORRELATION FOR ALTERNATIVE RESIST MATERIALS

Novel inorganic materials have been explored at imec towards outgassing



Outgassing vs. contamination relationship is slightly different compared to CAR.

Low 'cleanable' contamination is feasible.

**More investigation is required to check if current outgas test procedure needs to be revised for the alternative materials.**

# OUTLINE

Introduction : round robin variability

RGA outgas metric for contamination

Within-site relationship of outgas/contamination

Site-to-site relationship of outgas/contamination

How to use outgas contamination relationship towards  
'round robin' variability ?

Summary

# SUMMARY

In order to decrease the round robin variability between outgas sites, collaborative work is done between the outgas qualification sites in close cooperation with ASML. Control on key parameters such as temperature, CLR, and PS/A has found to be important.

In addition to the contamination growth (CG) from the witness sample testing, benefit has been found in the RGA outgas measurement, where simple analysis can provide complementary information (integrated COR). This RGA parameter is typically correlating very well with CG, and this correlation has been demonstrated on multiple sites.

It is expected that this approach is helpful in identification of within-site and site-to-site excursions of contamination results and help in understanding of contamination processes of advanced photoresists.

# ACKNOWLEDGEMENTS

ASML : S. van Pham, G. Rispens, and N. Harned

D. De Simone, and E. Hendrickx (imec) and Resist suppliers for providing resist samples and helpful discussions.

EUV Tech : C. Perera and D. Houser



**ASPIRE  
INVENT  
ACHIEVE**

