

---

# Detection capability for native defect by the actinic blank inspection

**EUVL Infrastructure development Center, Inc.**

Takeshi Yamane

**Lasertec Corporation**

Tomohisa Ino, Tomohiro Suzuki, Hiroki Miyai,  
Kiwamu Takehisa, Haruhiko Kusunose

# Outline

---

1. Introduction
2. Defects detected by ABI
3. Not detected defects by ABI
4. Summary

# Outline

---

1. **Introduction**
2. Defects detected by ABI
3. Not detected defects by ABI
4. Summary


# Actinic blank inspection (ABI) tools

MIRAI-tool  
(Full-field inspection prototype)




Developed by Selete and EIDEC  
Available since August, 2008

This work  
HVM ABI prototype




Developed by Lasertec and EIDEC  
Available since December, 2012

# Schema of Actinic Blank Inspection



# Defect sensitivity of HVM ABI prototype



Defect sensitivity of the HVM ABI prototype for 16 nm node was confirmed by the programmed defect evaluation

# Motivation of this work

---

## This work

Inspection capability of the HVM ABI prototype for 'native' defect on actual mask blanks was evaluated

- Mask blanks were inspected by the HVM ABI prototype and an optical inspection tool
- Native defects detected by ABI were observed with AFM and wafer impact of them was evaluated with simulation
- Native defects not detected by ABI were observed with AFM ArF microscope and SEM and analyzed with EDX, and also wafer impact of them was evaluated with simulation
- Readiness of ABI for 16 nm node was discussed

# Outline

---


1. Introduction
- 2. Defects detected by ABI**
3. Not detected defects by ABI
4. Summary



# Experiment


## Inspection by ABI

- Mask blanks were inspected with the HVM ABI prototype
- Defects detected stably (detected in all of 3 times inspection or indicated sufficient signal intensity for one inspection) were selected
- Punch marks were created near the selected defects



## AFM measurement

- The selected defects were observed by AFM
- Defect dimensions were measured  
Height / depth : peak / valley to background  
Width: average of vertical and horizontal FWHMs



Distribution of defect dimensions detected by ABI was obtained

# Simulation


## Defect signal intensity of ABI

Dimensions of phase defects where signal intensities were the same as 1 nm-high 36 nm-wide defect were calculated



Defect dimensions detected at 100 % capture rate by ABI were obtained

Conformal structure



## Wafer impact

Wafer impact of phase defects for 16 nm node was evaluated with variation of defect dimensions

### Exposure condition


NA 0.33, Dipole ( $\sigma=0.4/0.8$ , open angle 90 deg.)  
Defocus range  $\pm 75$  nm

A defect caused 10 % CD deviations → Printable



Defect dimensions printable for 16 nm node was obtained

Phase defect




16 nm L/S pattern

# Distribution of detected defect dimension

Using the dimension of defects detected by ABI, distribution of defect dimension was obtained


\*) Detection density =  $\frac{\text{Detection number in a certain range of dimension}}{\text{Total detection number}}$



1-1.5 nm-high/deep 40-50 nm-wide defects were the most detected


# ABI detectable and printable phase defects

Using simulation, dimensions of the ABI detectable and printable defects were obtained, and compared with the distribution of defect dimensions



- ✓ Existing printable phase defects were detected by ABI at almost 100 %
- ✓ Defect dimensions in the most detected area were 20 nm and smaller in SEVD

# Detection density vs. SEVD



46 % of printable defects was smaller than 20 nm in SEVD

# Outline

---

1. Introduction
2. Defects detected by ABI
- 3. Not detected defects by ABI**
4. Summary

# Not detected phase defect by ABI

ABI and optical inspection




Defects not-detected by ABI were collected



Among the not-detected defects, phase defects were extracted using AFM, ArF microscope and SEM and EDX



Not-detected but printable phase defects were extracted




- ✓ < 1 % of the total detection\*
- ✓ Aspect ratio (H or D / W) < 1/100

\*) Total detection = ABI (defects detected 3 times)  $\cup$  Optical inspection

ABI signal intensity and wafer impact of low aspect phase defects were calculated with simulation

# Measures to detect a low aspect defect



- ✓ Because defect dimensions where aspect ratio was lower than 1/100 were far from the concentrated defect area, it was hardly existed.
- ✓ The simulation result shows that a printable phase defect where aspect ratio was lower than 1/100 was not detected by ABI
- ✓ The optimized illumination setup enables to detect a low aspect but printable phase defect



# Outline

---

1. Introduction
2. Defects detected by ABI
3. Not detected defects by ABI
- 4. Summary**

# Summary

---

- Existing printable defects were detected by ABI at almost 100 % capture rate.
- Almost the half of printable defects was smaller than 20 nm in SEVD. The ABI could detect such a small but printable phase defect.
- Although a printable phase defect where aspect ratio was lower than 1/100 was hardly existed, it was not detected by ABI
- The simulation result shows that optimization of the ABI illumination setup enables to detect a low aspect but printable phase defect.

# Acknowledgement

---

**This work was supported by New Energy  
and Industrial Technology Development  
Organization (NEDO) and Japan Ministry of  
Economy, Trade and Industry (METI)**

**Experiments were assisted by Kenji  
Sakamoto, EIDEC**