



Recent advances in Mask Blank Deposition and Defect Reduction

Frank Goodwin, Alin Antohe, Patrick Kearney, Long He, HoJune Lee, Dave Balachandran, Anil Karumuri

SEMATECH, Albany NY


Key Defect Challenges for EUV HVM Mask Blanks

- Mask Defect Density
 - Mask Blank Defects > 80nm*
 - No defects > 80nm
 - Impacts yield of useable mask blanks and pattern masks
 - Majority are deposition defects
 - Mask Blank Defects < 80nm*
 - Limited counts are needed to enable mitigation
 - Typically substrate or surface defects which become decorated during deposition
 - Implementation of Mitigation Strategies
 - Feature level OPC
 - Pattern shift
 - Defect Repair
 - etc ,,,

* SiO₂ equivalent

Mask Blank ML Deposition

Veeco Nexus IBD Tool




- Ion Beam Deposition (IBD)
 - The leading technology for deposition of mask blank Si/Mo multilayers
 - Only technology used by mask blanks suppliers
- Recent deposition results at SEMATECH have now confirmed IBD can achieved defect level required to support HVM

IBD Defect Trend [2003- present]

Mask blanks processed at SEMATECH

Mask Blank Defect Density Trend (@>73nm SiO₂ equiv.)




- Defect density of all defects per mask blank
 - Includes substrate and handling defects
 - Data is measured on the LaserTec M1350 over 14.2x14.2cm² area

Closer Look at Recent Process Run

Mask blanks processed at SEMATECH

Mask Blank Defect Density Trend (@>73nm SiO₂ equiv.)



- Defect density of total mask blank defects over 14.2x14.2cm² area
- Best defect results where achieved over the last 48 mask blanks deposited
 - Si capped multilayer deposition
 - Cherry picked substrates
 - New ion optic Design

Characteristics of Recent Deposition Run

- Defectivity @> 73nm* (mask blank area of 14.2x14.2 cm²)
 - 2.8% of the mask blanks are defect free
 - 58% have single digit defect counts
- However
 - Just 3.6% of the single digit blanks have no defects larger than 80nm*
 - Increases to 6.4% for <10 defects with no defects larger than 100nm*
- Majority of the low defect mask blanks were Si capped
 - Deviation from SEMATECH POR which is Ru capped
 - Issues with sputtering Ru

* SiO₂ equivalent

Defect Composition

Preliminary analysis

ADDERS >100nm	M07	M16	M17	M19	M20
Fe, Ni	4%	6%	3%	36%	12%
Al/AlOx	17%	21%	13%	22%	7%
Ru	12%	2%	4%	5%	0%
Si/SiOx	7%	29%	17%	6%	6%
CA+C	5%	2%	26%	6%	9%
Mo / MoOx	0%	4%	1%	0%	11%
Other: Ti, Mo, Ni, Cu	0%	0%	1%	7%	2%
NO ID	54%	35%	35%	17%	54%
# of blanks	11	8	7	35	43

ADDERS >100nm	M07	M16	M17	M19	M20
Fe, Ni	0.6	1.6	0.6	4.3	0.3
Al/AlOx	2.8	5.3	2.3	2.6	0.2
Ru	2.0	0.6	0.7	0.6	0.0
Si/SiOx	1.2	7.4	3.0	0.8	0.2
CA+C	0.8	0.6	4.6	0.7	0.2
Mo / MoOx	0.0	1.0	0.1	0.0	0.3
Other: Ti, Mo, Ni, Cu	0.0	0.0	0.1	0.9	0.0
NO ID	8.8	9.0	6.3	2.0	1.4

- Preliminary analysis is for the recent process run M20
 - Samples still being processed
- Data is on defects > 100nm* in size
- Reduction seen in Al/AlOx, Fe/Ni, Ca/C defects
 - Significant decrease in Al/AlOx defects
 - Likely related to removal of IBD aligner from process flow


* SiO₂ equivalent

New Champion Data


08/12/14 08:57

[Sample Information]

Sample ID :
Lot ID :
Cassette/Slot No. : 2 - 1
WFD File : D:\def003a\Mask-142mm.wfd
Work Folder : Step 7900
LDF File : Lot_DRT1408004_7900_140812073658.ldf [Count = 3]
Sample Size : 152 mm
Comment :



Pixel Histogram




Single 65nm defect
outside quality area of
13.5x13.5cm²


08/06/14 13:09

[Sample Information]

Sample ID :
Lot ID :
Cassette/Slot No. : 2 - 1
WFD File : D:\def003a\Mask-142mm.wfd
Work Folder : Step 7900
LDF File : Lot_DRT1407055-90d_7900_140806114902.ldf [Count = 3]
Sample Size : 152 mm
Comment :



Pixel Histogram



Sensitivity cut-off: ~54nm

- Two Defect-Free Mask Blanks @ 54nm (SiO₂ equivalent)
 - 13.5x13.5 cm²

Process Deviations from POR

- Over the course of the deposition run there were several adjustments to the POR
 - Process optimization
 - Stricter process control for deposition
 - Modification to IBD tool configuration
 - Substrate management
- For the last 48 mask blanks deposited the improvement in defectivity has a first order correlation to:
 - Substrate management
 - Cherry picking substrates
 - Modification to storage after cleaning
 - Change in the ion optic to elliptical grid design
 - Part of Veeco's Odyssey upgrade package
 - Running Si capped multi-layers
- Correlation analysis on interaction effects has not been completed


Front-end and Material Handling of IBD Tool

- Material handling of SEMATECH's deposition tools are a known source of defects
 - Routinely adding 5-20(@54nm*) defects
 - Frequent spikes of > 100 adders
- Historically partitioning has not been able to isolate the defect sources
 - New partitioning techniques were introduced
 - Identified the front-end aligner and a chamber feed through as defect sources
- Stricter process controls instituted
 - Tool was not released for deposition if handling monitor had > 3 adder defects
 - Limited deposition to ~1 mask blank per day; manufacturability of IBD process will need to be demonstrated at suppliers

* SiO₂ equivalent

Influence of Handling Defects

Handling Defects (>73nm*)



- Towards end of process run handling defects improved
 - For the most part improvement coincides to improvement of deposition defects
 - All of the mask blanks with <10 total defects and 0 defects @ >80nm* where deposited during this period.

* SiO₂ equivalent

Status of IBD of Mask Blanks


- Technology has demonstrated capability to deposit quality mask blanks
- IBD process has improved but yield is low
 - Sustained quality deposition with low defect counts needs to be demonstrated
 - Without impacting capacity
- Veeco is currently exploring a new design of the ion optic and modification to the target turret
 - The new ion optic design was tested during this recent process run
 - All of the 0 defect mask blanks (@ 73nm*) were deposited using the new ion optic
 - Additional process changes may also have contributed to achieving these results
- Hurdles also remain in addressing substrate defects
 - Specifically the need for inspection capability with greater sensitivity

* SiO₂ equivalent

Summary

- New champion mask blank
 - Defect free at 54nm*
- From the most recent process run
 - Single digit defect counts on over 50% of the mask blank deposited
 - However, yield of quality mask blanks (0 defects @ > 80nm*) was just over 3.5%
 - Improvement of Al/AlO_x, Fe/Ni, Ca/C defects
 - Promising results achieved while using the new ion optic design
 - But not definitive
 - Further evaluation of Veeco's upgrade package is required

* SiO₂ equivalent



Thank You