


# Lasertec

EUVL symposium 2014



## Defect inspection and characterization on actinic blank inspection tool

**Lasertec Corporation:**

Hiroki Miyai, Tomohiro Suzuki, Kiwamu Takehisa, Haruhiko Kusunose

**EUVL Infrastructure Development Center(EIDEC):**

Hidehiro Watanabe, Ichiro Mori

**Lasertec**




# Contents

1. ABI tool development status
2. Defect printability
3. Defect characterization
4. Summary

# ABI tool development status


## Dark field inspection



Tsuneo Terasawa et al., Development of actinic full-field EUV mask blank inspection tool at MIRAI-Selete, Proc. of SPIE vol. 7271 (2009)




## Actinic inspection




K. Goldberg et al., "Defect detection and inspection unmasked", IWEUVL, 2010

## Capture Rate, Programmed defects



ABI HVM Tool is ready to play an important role in phase defect control

# EIDEC/Lasertec BI Program Schedule




1) BI Program: Blank Inspection program



# ABI tool – inspection performance


- The ABI tool inspected more than  $200 \times 10^4 \text{mm}^2$  in one year.
- Signal intensity has been stable during this period.
- The ABI tool meets the 16nm-sensitivity requirement and is currently being used for actual EUV mask blanks inspection.



The ABI tool has demonstrated its actinic inspection performance through a year of operation.

# ABI tool - review function

- Actinic review is available for all defects detected by the ABI tool.
- The ABI tool performed more than 80,000 reviews in one year.




Actinic review function is crucial for understanding defect characteristics

# Contents

1. ABI tool development status
- 2. Defect printability**
3. Defect characterization
4. Summary

# Previous studies on printability of phase defect


## Relation between Printability simulation and experiment



Simulation on bridge defect on wafer matched the experiment result.

Tsuneo Terasawa et al., EIDEC symposium 2013

## Simulation study for Wafer impact as a function of ABI intensity




Simulation shows ABI signal intensity proportionally correlated to defect intensity on wafer.

Noriaki Takagi et al., EIDEC symposium 2013




# Printing impact from ABI signal intensity

Experimental ABI signal intensity as a function of phase defect size



Simulated space width error on 16nm L&S



Tsuneo Terasawa et al., EIDEC,  
EUVL symposium 2012

ABI signal intensity represents wafer printing impact

# Contents


1. ABI tool development status
2. Defect printability
- 3. Defect characterization**
4. Summary

# Defect characterization – ABI flow


Defect  
Inspection

Low Magnification  
Review


High Magnification  
Review



Review of  
each defect



high  
resolution








-Defect map with DSI  
(defect signal intensity)

-False elimination  
-Phase / Amplitude  
defect classification

-Pit/Bump classification  
-Measurement of defect  
location and size

# Phase / Amplitude defect classification


Defect type	EUV review	DUV review
Phase Defect (H2.4nm, W200nm)		
Amplitude Defect (H50nm, W76nm)		




With EUV and DUV reviews, Phase/Amplitude can be distinguished.

# Pit and Bump - Through focus images

## Low magnification images



## High magnification images




The position where the image focuses differs, depending on whether the defect is pit or bump.




# Pit / Bump classification function

Through focus image analysis for pit/bump classification



Focus dependent intensity profiles for programmed phase defects

Pit / Bump classification result








judged from >100 samples of programmed defect and native defect


Details of focus dependency, see reference poster session “The influence of phase defect characteristics on scattered light images in actinic dark field inspection” Noriaki Takagi, EIDEC

With through focus image analysis, Pit/Bump classification is possible.

# Defect size measurement

Programmed phase defect images from high magnification optics

Defect width by AFM	72nm	101nm	108nm	120nm	154nm
Defect images by high Mag. review					
Defect Diameter from ABI images	55nm	76nm	95nm	112nm	120nm



With ABI high magnification review images, defect size measurement is possible.

Comparison of measurement results from ABI review and AFM

# Contents

1. ABI tool development status
2. Defect printability
3. Defect characterization
4. **Summary**

# Summary

1. The ABI HVM prototype performs EUV blank inspection and review to assist the efforts to develop better EUV blanks.
2. ABI review images facilitate the following defect characterization, which contributes to EUV blank defect management.
  - Phase/Amplitude classification
  - Pit/Bump classification
  - Defect size measurement

# Acknowledgements

This work was supported by New Energy and Industrial Technology Development Organization (NEDO) and Japan Ministry of Economy, Trade and Industry (METI).





Thank you very much  
for your attention.

**Lasertec**

This material contains confidential information.  
Neither copy nor disclose to any third party is authorized  
without prior written consent of Lasertec.