

Optimized EUV Mask Absorber Stack for Improved Imaging by Reducing Crystallinity of Alternative Absorber Materials



Vu Luong, Marc Heyns



Vicky Philipsen, Eric Hendrickx



Frank Scholze



Robbert R.W. van de Kruijs, Arash Edrisi




Obert Wood, Mandeep Singh

EUVL SYMPOSIUM 2016 – Hiroshima, JAPAN – October 24, 2016


IS CRYSTALLINITY IMPORTANT?

Crystallinity can be looked at from different perspectives




CRYSTALLINITY

Imaging modeling – Setting up the model



- Columnar grains of ~ 10 nm diameter spanning the full layer. Grains have slightly different optical constants from each other.



- Optical constants based on material density. Amorphous Ni density taken as 90% of crystalline Ni density*.

| | ρ [g/cm ³] | $n = 1 - c_1 \cdot \rho$ | $k = -c_2 \cdot \rho$ |
|--------------------------|-----------------------------|--------------------------|-----------------------|
| 1) Ni _{crystal} | 8.908 | 0.948 | -0.0727 |
| 2) Ni _{amorph} | 8.017 | 0.953 | -0.0655 |

* T.Q. Dong et al, Thin Solid Films, 2013

CRYSTALLINITY




Imaging modeling – Nearfield images

40nm HP – Horizontal Line
4x reduction
No ML mirror

Multi-grain Nickel



Single grain Nickel

Nearfield
Amplitude E_y



Seemingly no difference in the dominant E_y dimension.

Nearfield
Phase E_y



CRYSTALLINITY

Imaging modeling – Nearfield images




40nm HP – Horizontal Line
4x reduction
No ML mirror

Multi-grain Nickel

Single grain Nickel



Nearfield
Amplitude E_x

! Different scale



Grain boundary effect in the E_x dimension.

Nearfield
Phase E_x




Relatively much larger than the single grain case, but absolute amplitude is small.


How big is the impact of grain boundaries in Nickel on imaging?

CRYSTALLINITY



Imaging Impact (Lines)



Single Grain Ni absorber






Multi-grain Ni absorber



Small imaging impact by grain boundaries for investigated features.

IS CRYSTALLINITY IMPORTANT?

Crystallinity can be looked at from different perspectives




CRYSTALLINITY

MITIGATION STRATEGIES




- Doped absorber material
 - Co-sputtering of a dominant element with a dopant element → breaking of crystal lattice during deposition while preserving the density of dominant element
- Alloyed absorber material
 - Co-sputtering of two or more elements with different atomic sizes, hereby breaking the crystal lattice and forming thin film metallic glass (amorphous metal)
- Multilayer absorber stack
 - Using a second material as spacer to limit the layer thickness of the absorber material, hereby reducing crystal growth.
 - Multilayer structure allows for tuning the imaging behavior.

DOPED ABSORBER MATERIAL



DOPED NICKEL ABSORBER CHARACTERIZATION

- 10at% doped Ni successfully changes structure
- XRD: reduced crystallinity; XRR: reduced density; AFM: reduced roughness





Reduced roughness (0.3 nm → 0.1 nm) after doping

EUVL SYMPOSIUM 2016 – Hiroshima, JAPAN – OCTOBER 24, 2016

DOPING SENSITIVITY SIMULATIONS

- Assume small doping content ($\leq 20\text{at}\%$) with light dopant ($Z_{\text{dopant}} < Z_{\text{absorber}}$)
 \rightarrow assume density doped absorber \approx density pure absorber



Range sensitivity simulation valid for:





- 20at% doped absorber
- maximum 5% density reduction to pure absorber

DOPING SENSITIVITY SIMULATIONS




■ Imaging impact and M3D results

16nm Target –Trench






For ~30nm Ni absorber the imaging impact is not very sensitive to n&k variation by doping with a light element.

MULTILAYER ABSORBER STACK



PREVIOUS WORK ON MULTILAYER ABSORBER

- Experimental Ni-based ML absorber stack deposited.
- M3D effects were modeled for untuned ML absorber stack with equal periods.
- Depending on the ML mirror response, a tuned absorber can give better M3D effects.




Tunable imaging behavior predicted with simulations. What about spacer requirements from material point-of-view?


MULTILAYERED ABSORBER STACK

Ni/MgO ML absorber

- Spacer needs to:
 - limit absorber crystal growth
 - reduce templating effect of Ru
 - have anti-diffusion properties
- Additional advantages of MgO: slower dry etch rate than Ni, can be used as etch stop layer
- Imaging impact comparison with pure Ni absorber
 - Total thickness ~30nm for minimum BF shift in pure Ni
 - For low reflectivity:
 - 5 bilayers
 - High Γ -factor
(= ratio of absorber versus bilayer thickness)



See V. Philipsen presentation




MULTILAYERED ABSORBER STACK

Ni/MgO ML absorber – Imaging impact



Ref pure Ni absorber




ML Ni/MgO absorber



5 BiLayers Ni/MgO

$\Gamma = 0.84$

16nm Target – Horizontal Trench



16nm Target – H/V Trench





ML absorber tuned to low reflectivity; good M3D effects similar to single metal absorber thanks to high Γ -factor.




MULTILAYERED ABSORBER STACK

Ni/MgO ML absorber – Single bilayer characterization

XPS: Chemical state at interface



XPS through depth




Limited diffusion into MgO = good barrier material.

NiO and MgO peaks under noise levels.

MULTILAYERED ABSORBER STACK

Ni/MgO ML absorber – Single bilayer characterization

- XRD: Ru templating is still present at 7.5nm Ni. Peak blends in with noise level for thinner Ni. No visible peaks with MgO spacer.



MgO spacer successfully reduces Ni crystal size.

CONCLUSION

- The work until now has achieved
 - Single metal Ni absorber is optimal imaging-wise, but challenging for processing
 - We explore some mitigation strategies from a material point-of-view (experimentally) and from imaging point-of-view (simulation)
 - Doped absorber optically very similar to single metal absorber
 - Multilayer stack with MgO spacer reduces crystallization and can be beneficial for processing; optically it's also very similar to single metal absorber
- Next steps
 - Exploring alloyed absorber material
 - Patterning Ni/MgO ML absorber and doped absorber

THANK YOU

Sven Van Elshocht, Christoph Adelman, Sofie Mertens, imec / Thin Films

Hilde Tielens, imec / FPE

Thierry Conard, Hugo Bender, Olivier Richard, imec / MCA

Laurent Souriau, imec / ETCH

Weimin Gao, Synopsys

Emily Gallagher, Rik Jonckheere, Kurt Ronse, Nadia Vandenbroeck, imec / AP


Prof. Dr. Marc Heyns, imec-KULeuven (PhD-promotor)

and Thank You for listening!

ACKNOWLEDGEMENTS



This project has received funding from the Electronic Component Systems for European Leadership Undertaking under grant agreement number 662338. This Joint Undertaking receives support from the European Union's Horizon 2020 research and innovation programme and Netherlands, France, Belgium, Germany, Czech Republic, Austria, Hungary, Israel.



 **umec**